

E-322



WARNING

This manual is for the exclusive use of dealers accredited by Motrec International Inc. and should not be considered an official document constituting any kind of guarantee for the end user. All information and data are subject to change without notice. All photos contained in this document are for illustrative purposes only and may include non-applicable options.

PARTS:

It is recommended that part numbers be confirmed with Motrec International Inc. before ordering by providing the serial number of the vehicle requiring the part. In some cases, the part installed on the vehicle may differ from the manual depending on the options chosen.

Publication date:

July 1, 2015

Edition for vehicles with
a serial number higher than:

1034667

For additional information,
please contact our customer service:

MOTREC INTERNATIONAL INC.

200 Des PME Street
Sherbrooke, Quebec J1C 0R2
Canada
1-866-846-3558

AVERTISSEMENT

Ce manuel est destiné à l'usage exclusif des concessionnaires accrédités par Motrec International Inc. et n'est pas considéré comme un document officiel pouvant servir de garantie pour l'utilisateur final. Les informations et données sont assujetties à des changements sans préavis. De plus, les photos présentées sont à titre indicatif seulement et pourraient inclure des options non applicables.

PIÈCES:

Il est recommandé de valider les numéros de pièces avec Motrec International Inc. avant de commander, en fournissant le numéro de série du véhicule pour lequel la pièce est requise. Dans certains cas, il est possible que la pièce installée sur le véhicule diffère du manuel en fonction des options choisies.

Date de publication:

1^{er} juillet 2015

Édition destinée aux véhicules ayant
un numéro de série supérieur à:

1034667

Pour toutes informations additionnelles,
contactez notre service à la clientèle:

MOTREC INTERNATIONAL INC.

200, rue des PME
Sherbrooke, Québec J1C 0R2
Canada
1-866-846-3558

MOTREC



E-322



OPERATOR AND MAINTENANCE MANUAL SPARE PARTS LISTS INCLUDED
--

SERIAL NUMBER : 1034667 & UP

Printed in Canada

One Year Limited Warranty

Effective April 25, 2005, Motrec International Inc. (MOTREC) hereby warrants to the Original Retail Purchaser (Owner) that any of its vehicles shall be free from any defect in materials for a period of 90 DAYS while in the possession of such Original Retail Purchaser. This warranty IS NOT TRANSFERABLE to any subsequent Buyer.

The warranty period is extended to one year or one thousand (1,000) hours, which ever first occurs, on the electric motor, differential (parts that bathe in oil) and the electronic speed controller. MOTREC makes no warranty or representation with respect to the internal combustion engine, tires and batteries, since their respective manufacturers cover such parts. Accessories (light, gage, horn, etc), electrical contacts (switch, solenoid, contactor, relay), diodes & fuses, belts & pulleys, filters & spark plugs, lubricants, brake linings & shoes, brake drums & discs, seals, seats, trim and other items subject to wear are not included in this warranty; nor is any item that in MOTREC sole opinion, shows evidence of neglect, misuse, abuse, collision or alteration.

This warranty shall not apply to normal maintenance requirements as described in the User Manual, and to damages during shipment. The latter is the carrier's responsibility. No compensation will be allowed for delays.

To initiate warranty coverage on any MOTREC vehicle, the Dealer must complete and return the "Sales/Installation Report" to MOTREC within 30 days after delivery to the Original Retail Purchaser; or within 90 days after the delivery date to the Dealer, which ever occurs first. Failure to follow these procedures will result in considering the warranty coverage effective as of the shipment date from the factory.

The defective vehicle must be returned, at the Owner's expense, to an authorised MOTREC Dealer within 30 days after failure. The Owner will not be charged for parts and labour required for warranty repairs, which must be performed by an authorised MOTREC Dealer only. The vehicle will be returned at the owner's expense. The Warranty Claim Forms must be completed and returned with the defective part(s) to MOTREC within 30 days after repair was done. No compensation will be allowed for damages caused by vehicle downtime.

It is the responsibility of the owner of the vehicle to make sure that the driver is properly trained and instructed in the safety features and operation of the vehicle, including vehicle stability, as required by OSHA and ANSI-B56. Operators shall read, understand and follow the safety and operating instructions in MOTREC Manual before driving the vehicle. Operators shall not be permitted to drive the vehicle unless a complete and adequate training has been provided. Driving a vehicle constitutes a hazard. The driver is responsible for the control of the vehicle while driving and must always evaluate and care for all peculiar situations that he or she may meet while driving. The driver assumes the inherent hazards related to this activity. The vehicle is designed for off-road use only. MOTREC disclaims any liability for incidental or consequential damages, to include, but not be limited to, personal injury or property damage arising from vehicle misuse, lack of maintenance or any defect in the vehicle.

It is the responsibility of the Owner of the vehicle to make sure that the service technicians are properly trained as required by OSHA and ANSI-B56. Service technicians shall read, understand and follow instructions in the MOTREC manual before servicing the vehicle. Only qualified and authorized personnel shall be permitted to maintain, repair, adjust and inspect the vehicle.

MOTREC prohibits, and disclaims responsibility for, any vehicle modification altering the weight distribution and stability, increasing the speed or affecting the safety of the vehicle. Such modifications can cause serious personal injury or property damage for which MOTREC disclaims any responsibility.

For Owners that are located outside North America, the warranty period starts the date of shipment from the factory, and the defective parts must be returned at the Owner's expense to MOTREC prior to warranty repair.

TABLE OF CONTENTS

ONE YEAR LIMITED WARRANTY	2
INSTRUCTIONS	4
SAFETY WARNINGS FOR OPERATORS	5
OPERATING INSTRUCTIONS	6
MAINTENANCE	7
SAFETY WARNINGS FOR SERVICE TECHNICIANS	8
DECALS AND LABELS	10
PERIODIC MAINTENANCE CHECKLIST	11
ACCELERATOR	12
HYDRAULIC & PARKING BRAKES	15
FRONT AXLE AND STEERING	16
BATTERY MAINTENANCE	17
BATTERY CHARGER	19
ELECTRICAL TROUBLESHOOTING	20
CURTIS SPEED CONTROLLER 1243	23
WIRING : STANDARD CONFIGURATION	25
DIAGNOSTICS AND TROUBLESHOOTING	26
TROUBLESHOOTING CHART	27
LED DIAGNOSTICS	29
PROGRAMMING PARAMETERS – E-300, E-302, E-322 & E-330	30
SPARE PARTS	31
BODY	32
CAB	33
DIFFERENTIAL	34
HYDRAULIC DRUM BRAKES	36
HYDRAULIC BRAKE CONTROLS	37
FRONT ASSEMBLY	38
MOTOR AND DRIVE	40
REAR SUSPENSION AND BRAKE	41
ELECTRICAL DIAGRAM – SEPEX MAIN CIRCUIT	43
DIAGRAMME ÉLECTRIQUE – CIRCUIT PRINCIPAL SEPEX	43
ACCESSORIES – NO DC/DC CONVERTER	44
ACCESSOIRES – SANS CONVERTISSEUR DC/DC	44
ACCESSORIES – DC-DC CONVERTER	45
ACCESSOIRES – CONVERTISSEUR DC-DC	45
OPTIONS	46
BATTERY CONFIGURATIONS - 36V	48
CONFIGURATIONS DES BATTERIES – 36V	48
BUILT-IN CHARGER MODEL 6430-00	49
PORTABLE CHARGER MODEL 07710-02	50
BUILT-IN/PORTABLE 40A CHARGER	51
BUILT-IN/PORTABLE CHARGER MODEL 16360-40	52
DELTA-Q HF CHARGER	53
MOTREC ILLUSTRATED ACCESSORIES	56
BATTERY DISCHARGE INDICATOR (HOBBS)	58
ADDENDUM	59
CURTIS FOOT PEDAL	60

INSTRUCTIONS

SAFETY WARNINGS FOR OPERATORS

- FAILURE TO OBEY THE FOLLOWING SAFETY RULES MAY RESULT IN SEVERE INJURY.
- It is the responsibility of the owner of this vehicle to train operators to ensure that they understand the operating characteristics of this vehicle, including training in vehicle stability, and obey the following safety rules and guidelines. Owner shall comply with OSHA and ANSI/ITSDF B56.8 & B56.9 Standards for vehicle use, safety rules, operator training and certification. Do not drive this vehicle unless you are a qualified operator.
- Do not drive this vehicle under the influence of drugs or alcohol.
- Do not drive this vehicle on public roads and highways. This vehicle is designed to be driven in buildings.
- The electrical system of this vehicle will make sparks which can ignite inflammable materials. Never use the vehicle in hazardous areas where there are inflammable materials, explosive dust or fumes in the air.
- Have your vehicle inspected regularly by trained personnel, and cease operation if a malfunction occurs.
- Do not open battery compartment to prevent battery explosion, acid splashing, severe damage to eyes or skin.
- Do not open motor compartment. Keep clear from moving, rotating(wheels, sheaves, etc) or lifting parts.
- Never carry more passengers than number allowed for this vehicle. Wait until all occupants are seated and holding on before moving. Always keep all body parts inside vehicle. Keep both hands on steering wheel.
- Do not exceed the vehicle cargo load capacity and gross trailing weight capacity, rated for flat hard even surface. Different operating conditions such as loose terrain or ramps reduce vehicle capacity.
- Avoid loose, unbalanced or top-heavy loads to keep a good stability and prevent overturn. Do not load cargo that can fall off the vehicle. Do not carry cargo that is longer, wider or higher than this vehicle.
- Always depress slowly the accelerator for smooth acceleration. Avoid stunt driving or horseplay.
- Avoid sharp turns, always slow down before turning, to prevent vehicle overturn or trailer jack knife. Vehicle is more sensitive to overturn and jack knife when traveling on inclines or when carrying a heavy load.
- Always drive straight up and down the face of an incline, never across the face, to prevent overturn and trailer jack knife. Drive slower and start applying brakes sooner on inclines to adjust for longer stopping distance.
- Use extra care and drive slowly in reverse, in congested areas or on wet or slippery ground.
- Keep to the right under normal conditions. Maintain a safe distance from all objects.
- Slow down and sound the horn when approaching a corner or other blind intersections.
- Before leaving the vehicle, park on a level ground flat surface, turn off all switches, set the forward/reverse switch to neutral, set the parking brake, remove the key. Do not park the vehicle on an incline.
- Before battery charging, park the vehicle in a well ventilated area set for. Do not operate it when charging. To interrupt a charging cycle, disconnect the AC plug; disconnecting the DC plug or a battery terminal, or operating the vehicle, could damage the charger and produce a spark, battery explosion and acid splashing.
- Use another driver to steer this vehicle while it is towed. Be sure the driver uses brakes when you slow or stop the towing vehicle. Do not exceed 5 MPH or carry any passenger while towing this vehicle.

OPERATING INSTRUCTIONS

It is the responsibility of the owner of this vehicle to ensure that the operator understands the operating characteristics of this vehicle, and obeys the safety instructions in this manual and ANSI/ITSDF B56.8 & 9 Standards. Do not drive this vehicle unless you are a certified operator as required by OSHA.

BEFORE TURNING ON KEYSWITCH

Set to neutral, set parking brake, check for visible damage, check brake pedal.

AFTER TURNING ON KEYSWITCH

Check safety devices: seat switch, reverse alarm, motion beeper, strobe light, and all other safety devices.

BATTERIES

Never open the battery compartment unless you have received proper training for battery maintenance.

Batteries emit explosive hydrogen gas that can be ignited by a spark or loose terminal. Battery acid causes severe damage to eyes or skin. Flush the contaminated area immediately with water. Park the vehicle in a well ventilated area for battery charging. Most battery chargers come with an electronic control that starts when the charger is plugged and stop when the battery is fully charged. To interrupt the charging cycle, disconnect the AC-plug, do not disconnect the DC plug.

BATTERY DISCHARGE INDICATOR

The green light moves from right to left as batteries are being discharged. When the green light is at the last position on the left the batteries must be recharged. A flashing light warns the operator that further discharge will damage batteries. See HOBBS indicator instructions.

EMERGENCY SAFETY DEVICE

The emergency push button or battery disconnect handle, when present, should only be used in case of emergency. Use the key switch for normal ON/OFF control.

KEYSWITCH

Depress brake pedal and turn the key switch clockwise for on position. Always turn off all switches, set the F/R selector to neutral, set the parking brake, remove the key before leaving the vehicle.

HORN

Depress the horn button on the steering column or handle bar.

F/R SWITCH

Three positions with neutral at center. Depress the front part of the rocker switch for forward direction. Depress the rear part of the rocker switch for reverse direction. Always set switch to neutral, turn off all switches, set the parking brake, remove the key before leaving the vehicle.

ACCELERATOR PEDAL

It is designed for right foot operation only, and controls the speed of the vehicle. Apply slowly.

FOOT BRAKE PEDAL

It is designed for right foot operation only. The brake force is proportional to the pressure on the pedal.

PARKING BRAKE

Pull handbrake lever to apply. Never park the vehicle on an incline. Always turn off all switches, set the F/R selector to neutral, set the parking brake, remove the key before leaving the vehicle.

MAINTENANCE

SAFETY WARNINGS FOR SERVICE TECHNICIANS

FAILURE TO OBEY THE FOLLOWING SAFETY RULES MAIN RESULT IN SEVERE INJURY.

Owner shall comply with OSHA and ANSI/ITSDF B56.8 & B56.9 Standards for vehicle maintenance.

Only qualified and authorized personnel shall be permitted to maintain, repair, adjust and inspect carriers, vehicles, tractors, and batteries.

Before any maintenance work, park the vehicle on flat level surface, turn off all switches, remove key, lift wheels off the ground and secure with jack stands of adequate capacity. Don't connect charger.

Keep clear from moving parts such as tires, sheaves and motor.

Follow the maintenance instructions applicable to the type of repair, maintenance, or service.

Always wear a face shield and gloves when working around batteries.

Before opening the battery compartment, disconnect the charger, turn off all switches and remove the key. Batteries emit highly explosive gases which greatly increase when charging; do not disturb connections or produce sparks around batteries to avoid a battery explosion and acid splashing. Battery acid causes severe damage to eyes or skin. Flush contaminated area immediately with water.

Use insulated tools to avoid sparks that can cause battery explosion and acid splashing.

Use two counteracting tools, double-wrench technique, when disconnecting or tightening terminals on the battery and the speed controller to avoid cracking the terminal or battery post welds.

Before cleaning or replacing a battery, charger, speed controller, contactor, relay, diode, or any other component in the power circuit, always disconnect the charger, turn off all switches, remove the key, wear a face shield and gloves, identify battery polarity and disconnect battery leads, discharge the capacitor in the controller with a 10 ohms, 25 W resistor for a few seconds across B+ and B-.

After cleaning, the power must not be reapplied until terminal areas are thoroughly dry.

On EE-Rated vehicles make sure that the control box is sealed, the static strap makes good contact with the ground, the motor is sealed by bands, the cable protectors are properly installed.

Keep cables and wires clear from mechanical and rubbing action. Make sure that cable insulation is free from cutting or visible damage. Make sure that EE-Rated cable protectors are properly installed.

Before replacing a fuse or circuit breaker, identify the cause of failure and repair.

Programmable controllers must be programmed using the parameter settings in this service manual, before connecting the motor, to avoid sudden vehicle movement and accident.

Do not try to increase motor speed by changing parameter settings in the speed controller; it can cause accident and severe damage to the motor.

SEPEX speed controls are protected by a diode in the power circuit to filter inductive loads in the event of a sudden power interrupt. Some speed controllers require a diode to filter inductive loads on the KSI input. Removing the diodes will cause the speed control failure.

Before resuming maintenance operations, inspect safety warnings stickers and replace any if damage is found and part of the text can't be read.

Check decals and labels, see "DECAL AND LABELS" page.

DECALS AND LABELS

! CAUTION !

The images included in this section depict the decals/markings installed on the vehicle. It is of the utmost importance that these decals/markings remain unaltered and readable. Else, the sticker or the part bearing the marking has to be replaced.


Dashboard security warning label:
5100000002



When an emergency push button is installed, this label is required (located under push button): # 3109800006



General security warning label:
5100000001



When a disconnect handle is installed, this label is required (located in front of handle):
4800012J



Respectively, key switch markings, forward/reverse selector markings and light switch marking:



266211



2819321003



1269004

PERIODIC MAINTENANCE CHECKLIST

FOR MODELS WITH TOWING CAPACITY UP TO 16,000 LB (7270 KG)

REVISION 12-01-23

! WARNING !

Maintenance operations must be made by properly trained service technicians.

- Keep clear from moving parts such as tires, sheaves and motor.
- Check for all EE protections, when applicable, and keep cables and wires clear from mechanical and rubbing action
- Batteries contain sulphur acid that can cause severe burns on skin or eyes.
- When working around batteries, wear acid proof protective equipment: face shield and gloves.
- Use electrically insulated tools to avoid sparks that can cause battery explosion.
- Before any maintenance work, park the vehicle on a flat level surface, turn off all switches, remove the key, lift the wheels off the ground and secure with jack stands of adequate capacity, identify and disconnect battery leads. Don't connect the charger.

CHECK/PERFORM	PERIOD HOURS	DAY	WEEK 20	MONTH 50	QUART. 200	YEAR 1000	2 YEARS 2000
MECHANICAL DAMAGE, OIL LEAKS		X					
REVERSE ALARM, DEADMAN SWITCH		X					
STATIC STRAP, min 2" contact with ground		X					
TIRE PRESSURE, pressure rating on tire			X				
CHECK/FILL BATTERIES, add distilled water to cover plates. Fill to recommended level after batteries have been fully charged.			X				
WARNING DECALS & MARKINGS				X			
EE-Rated CABLE PROTECTORS, SEALED MOTOR, SEALED CONTROL BOX, STATIC STRAP.				X			
MASTER CYLINDER FLUID (DOT 3)				X			
BRAKE PEDAL TRAVEL 2" (50 mm) maximum travel				X			
STEERING FOR PLAY				X			
PARKING BRAKE LEVER requires 30-40 lbs. (14-18 kg) force to apply				X			
BELTS AND PULLEYS -10 lbs (5kg). force for 1/8" (3mm) deflexion; -pulleys alignment, see procedure.					X		
CLEAN/TIGHTEN WIRE TERMINALS					X		
WASH BATTERY TOP WITH WATER					X		
MOTOR BRUSHES FOR WEAR -brushes must exceed holders					X		
ACCELERATOR ADJUSTMENT -1/8" (3 mm) travel to activate micro-switch; -0 to 50 ohms when micro-switch activated; -4500 to 5500 ohms with pedal down.					X		
HYDR. BRAKE LINES FOR LEAK					X		
STEERING ASSEMBLY, as instructed					X		
BRAKE MECHANICAL LINKAGES for wear & play					X		
BRAKE LININGS FOR WEAR 1/16" (2 mm) minimum lining thickness. 6 mm minimum thickness for brake-pulley lining.					X		
LUBRICATE (GREASE EP-2) brake pedal pivots, steering column, ball joints and kingpins.					X		
OIL (SAE 30) LEVEL IN DIFFERENTIAL Before adding oil, check oil seals for leaks.					X		
FRONT WHEEL BEARINGS PLAY					X		
TIGHTEN NUTS/BOLTS, electric terminals; drive; steering; brakes; suspension; body.					X		
REPLACE DIFFERENTIAL OIL(SAE 30)						X	
CLEAN AND RE-PACK FRONT HUBS						X	
SERVICE DIFFERENTIAL, replace the three oil seals, wheel bearings, oil (SAE 30)							X

ACCELERATOR

GEAR

- Remove the cover.
- Backlash between gears must be reduced to a minimum by sliding holder; use locktite 262 to lock the three screws.
- When the plastic gear is fully depressed a small backlash must remain between the gears.
- When the plastic gear is released its rear portion must not exceed the pedal case.


MICRO-SWITCH

The micro-switch must deactivate the on/off solenoid when the accelerator is released; turn the adjusting screw (shown on figure below) to adjust the micro-switch height.

POT

- Remove the terminals 2 and 3 on PMC to measure resistance signal.
- When the micro-switch is activated the signal must be less than 50 ohms. When the front portion of the pedal is fully depressed the signal must be more than 4600 ohms.
- To modify the resistance, turn the adjusting screw to change the micro-switch height (see figure below).

Proceed with the same verifications after the accelerator cover is on and then connect terminals 2 and 3.



FOOT PEDAL FP-6 MAINTENANCE GUIDELINES

FEATURES -

- FP 6 is designed for IP rating 64
 - It can work in dusty atmosphere.
 - It has sealing against splashing and spraying water from all side.
 - We do not recommend low pressure or high pressure washing.

SPECIFICATIONS -

- Pedal high point is pedal free condition
- 1st Microswitch Setting ;
 - a) First micro switch should operate at $3^\circ \pm 1^\circ$ (i.e. between 2° to 4°) from free condition
- Pot setting
 - a) Operate pedal slowly; find reading at which first Microswitch operates.
 - b) Pot resistance reading across pot low and wiper (i.e. black and white) must be within 100Ω to 400Ω.
- 2nd Micro switch setting
 - a) 2nd micro switch should operate between 4600 Ω and *pot max* resistance, across *pot low and wiper* (i.e. black and white)

INSTALLATION PROCEDURE

Terminology - "**Pot low**", "**wiper**" and "**pot high**" are pot terminals. (Black, white and red cables respectively) "**Pot max resistance**" is the resistance value across pot low and pot high. (Black and Red cables)

1. MICRO SWITCHES AND POT SETTING

For Foot Pedal FP-6, use pot low and wiper (black and white) for setting micro switches.

- Set Pedal at free condition.
- Adjust pedal at 3° deflection. Set first micro switch to operate about set deflection.
- Adjust pot resistance from high valve to get (100 to 400Ω) across *pot low and wiper* (i.e. black and white).
- Set 2nd micro switch between 4600 Ω and *pot max* resistance.

CHECK LIST / CAUTION

- Pedal angle must be within 30 +/- 3 degree. Check freeness of pedal.
- Select 'resistance' measurement range in as per requirement on the Multi meter. Minimum resistance between pot low and wiper must be less than 10 ohms. Pot Max Resistance (between pot low and pot high) must be within 4500 to 5500 ohms.
- Confirm that micro switch settings are as per specifications.
- Measure the resistance between each of the seven wires and the housing of the Foot Pedal. It should measure "Infinity"
- Visually check the insulating sleeves are put around the soldered side of all seven cables, and that the sleeves are firmly in place.

YEARLY MAINTENANCE

- Remove cover of Pedal.
- Apply 3 to 5 drops oil on pedal return spring.
- Apply 2 drops oil in the slot of front bush.
- Do not apply oil on shaft from outside. It is of no use, due to sealing on the shaft.
 - i. Oil Specification
 - ii. 20W Motor Oil (Or 3 in one motor oil)
 - iii. 20 stand for weight of motor oil.
 - iv. W Stands for winter grade.

HYDRAULIC & PARKING BRAKES

FOR MODELS WITH TOWING CAPACITY UP TO 16,000 LB (7270 KG)

Revision 2012-01-23

DRUM BRAKES

Remove brake drums and check lining wear. Replace shoes and springs if the lining thickness is 1/16" (2mm) or less. Turn the brake adjustment to reduce the clearance between lining and drum. Wheels must turn free when the pedal is released.

DISC BRAKES

Check pad linings. Replace pads if lining thickness is 1/16" (2 mm) or less.

PARKING BRAKE

Replace cables and stoppers if cable play exceeds 1/8" (4mm).

Wheels and/or differential pinion must turn freely when the parking brake is released.

On pinion brake, use spacers at pad fixed ends to reduce space between pads and pulley to 1mm.

To install new cables and stoppers:

- insert the new cable through the hand lever end;
- pull the cable out from the brake assembly end;
- insert the stopper on the cable and leave a maximum play of 1mm;
- for a two-cable system, make sure that cable length is the same at hand lever end;
- tighten 1/4-ncx3/4 grade-5 bolt in stopper at 8 Lb-Ft (11Nm) torque;
- cable must extend 1.5" (4cm) out of the cable stopper, cut cable excess.

Once cable play has been checked and/or adjusted, turn the knob on the brake lever until a force of 30-40 Lbs or 14-18 kg is required on the handle to set the parking brake. Tighten the locking screw.

BRAKE PEDAL

If the brake pedal becomes soft or spongy, air may have entered the hydraulic system and the brake system has to be bled:

1. fill the master cylinder with brake fluid (DOT-3);
2. bleed front calipers one at a time by having someone applying a steady pressure on the brake pedal, and close the bleeder before allowing the brake pedal to return to up position;
3. fill the master cylinder with brake fluid (DOT-3);
4. bleed rear wheel brakes one at a time, following the same procedure;
5. fill the master cylinder with brake fluid (DOT-3);
6. clean every fitting and line, remove traces of oil;
7. apply a continuous pressure on the brake pedal for about five minutes ;
8. Finally, inspect brake lines and fittings for leaks ;

FRONT AXLE AND STEERING

! CAUTION !

Before maintenance, turn off all switches, set to neutral, set parking brake, remove the key, and raise the front end of the vehicle supporting it with two jack stands of adequate capacity

STEERING INSPECTION

- Check tire inflation pressure, suspension components, tie rods straightness, tie rod ends play (wear), play (wear) in wheel bearings, kingpins and bushings.

REPLACING & ADJUSTING THE STEERING GEAR

- Remove the pitman arm;
- The steering box makes 6.5 turns, center the steering gear (3.25 turns from either side);
- Align the front wheel straight. Install the pitman arm.

TOE-IN ADJUSTEMENT

- With the wheels in straight forward direction, measure the inside (left to right) distance between the front tires, at the front and rear of the tires;
- Turn the rear tie rod until the distances are equal and tighten the two lock nuts on the tie rod.

REMOVING & GREASING OF FRONT HUBS, required once-a-year

- Remove dust cap and cutter pin, unscrew nut, remove hub;
- Inspect bearings and races for wear and replace worn bearings;
- Replace the seal;
- Pack the hub with wheel bearing grease and re-assemble.

ADJUSTING FRONT HUBS

- Tighten spindle nut to 30 ft-lb to seat the bearing and back off the nut to the next slot;
- Install a new cutter pin and the dust cap.

BATTERY MAINTENANCE

! WARNING !

- It is the responsibility of the owner of this vehicle to ensure that the service technicians are properly trained, read and obey the safety rules and guidelines in this manual (ANSI B56).
- Maintenance operations must be made by properly trained service technicians only.
- Before any maintenance work, park the vehicle on a flat level surface, turn off all the switches, set to neutral, remove the key, lift the wheels off the ground and secure with jack stands of adequate capacity.
- Keep charger disconnected while doing any maintenance work.
- Always wear a face shield and scarf when working around batteries.
- Battery emits highly explosive gases; do not produce sparks to avoid battery explosion and acid splashing. Battery acid causes severe damage to eyes or skin. Flush contaminated area immediately with water.
- Use insulated tools to avoid sparks that can cause battery explosion and acid splashing.
- Use two counteracting tools, double-wrench technique, when disconnecting or tightening battery posts.
- Before cleaning or replacing a battery, discharge the capacitor in the controller with a 10 ohms, 25 W resistor for a few seconds across B+ and B-, identify battery polarity and disconnect battery leads.
- After cleaning, the power must not be reapplied until terminal areas are thoroughly dry.

BATTERY LEADS AND CONNECTORS

Check for loose connections, damaged cables, acid spill, loose terminal posts, quarterly.

BATTERY POST CORROSION

If corrosion is present on battery posts, remove the cable connectors, use a wire brush to remove particles, and then clean them with a cloth that has been moistened with ammonia.

ELECTROLYTE LEVEL

Does not apply to sealed battery.

- Disconnect battery connectors on roll-out or lift-out installations.
- Make sure the battery roll-out tray is provided with stops before rolling out.
- Fill with distilled water.
- Daily charged batteries normally require watering once a week. Under watering leads to a shortened battery life. Over watering leads to battery corrosion. Be careful not to overfill any cell to avoid electrolyte to be forced out while charging.
- Fill each cell to plate level with distilled or de-ionized water, before battery charging. When the battery is charged, the fluid expands and can seep out if overfilled. Refill each cell after full charge, when the fluid has expanded to its maximum level.
- Reinstall battery caps before charging.

BATTERY MOUNTING

A loose battery increases damaging effects of vibrations and is more prone to short out.

BATTERY DISCHARGE LIMIT

Discharging below a 20% state of charge cuts down the battery life and the number of cycles available. At 20% state of charge, specific gravity of 6V battery should be 1180; and 1220 for industrial battery.

CHARGING AREA

- Always charge battery in a well ventilated area set for and approved for charging.
- Never leave a charger connected for more than 20 hours.

FREQUENCY OF CHARGE

- When a battery is discharged to its 20% state of charge, it is best to charge immediately.
- Batteries require a low current equalization charge (min 4 hours) at least every week, to equalize battery cells, improve battery performance and life in number of cycles.
- Never leave a charger connected for more than 20 hours.

STORAGE

- Keep the battery from getting cold, it would lose its capacity.
- Let the battery warm up before charging.
- Charge batteries in “stored” vehicles every month.

DEFECTIVE BATTERY

Check specific gravity of each cell; if a cell is shorted, voltage drop may occur only when there is current.

BATTERY CHARGER

! WARNING !

Always unplug the AC and DC electrical cords before attempting any repairs to the charger.

CHARGER DOES NOT TURN ON:

- Dc cord of portable chargers must be disconnected from batteries after every charge to restart;
- Check dc fuse links;
- Check battery voltage at the battery connector;
- Check ac outlet and cordset;
- Replace electronic control ;

RELAY CLOSSES AND TRANSFORMER HUMS BUT AMMETER DOES NOT REGISTER:

- Check dc fuse links;
- Check the continuity of the dc output cord, ammeter, diodes and all connections in the dc circuit;
- Check diodes;
- Check capacitor(rapidely increasing resistance);

SINGLE CHARGER FUSE BLOWS:

- Disconnect and check diodes;

BOTH FUSE LINKS BLOW:

- Check the battery pack and battery connector polarity;
- Disconnect and check diodes.

CHARGER OUTPUT IS LOW:

- Disconnect and check diodes;
- Can be caused by a transformer failure.

AMMETER READS 30 AMPS FOR MORE THAN 30 MINUTES:

- Check the battery pack;

CHARGER DOES NOT TURN OFF:

- Check specific gravity in each battery cell;
- As much as 16 hours may be required to properly charge heavily discharged new or cold batteries;
- Replace electronic control.

AC LINE FUSE OR CIRCUIT BREAKER BLOWS:

- Check ac cordset;
- Check ac line fuse rating;
- Replace electronic control;
- Can be caused by a transformer failure.

ELECTRICAL TROUBLESHOOTING

! WARNING !

Maintenance work must be performed by trained service technicians only.

It is the responsibility of the owner of this vehicle to ensure that the services technicians are properly trained, understand and obey the safety rules and guidelines (ANSI B56).

All service technicians must read and understand the maintenance warning section in this manual.

! WARNING !

Before any maintenance work, park the vehicle on a flat level surface, turn off all switches, remove the key, lift the wheels off the ground, secure with jack stands of adequate capacity, disconnect charger.

Always wear safety glasses.

Batteries emit highly explosive gases that can be ignited by a spark. Before disconnecting a high current terminal, turn off all switches, disconnect battery charger, disconnect batteries.

Keep clear from moving parts such as tires, sheaves and motor.

PMC SELF DIAGNOSTIC

If your PMC comes with a status led, use the flashing code to help troubleshooting.

BATTERY VOLTAGE

Make sure batteries are securely connected. Measure voltage between + and - terminals. We will call this value B+ or full battery voltage.

ACCESSORIES NOT WORKING

- Check the fuses on the batteries and the DC/DC converter.
- Check voltage across + and – terminals on the battery gage; if not B+, check wiring.
- Turn the key switch ON, check voltage between output terminal on the key switch and the - terminal on the battery gage; if not B+, replace the key switch.
- Check voltage across DC/DC converter output terminals; if not 12-Volt, replace the converter.
- Depress the accessory switch, check voltage across accessory terminals. If not 12-Volt, replace the switch. If 12-Volt, replace the accessory.

FORWARD ONLY

On a SEPEX motor control, check the reverse signal input on the controller.

On a series wound motor control, a bad reverse contactor is the most probable cause of the problem.

Switch to reverse and check voltage on the reverse control wire. If not B+, replace the F/R switch. If B+, turn off the key switch, disconnect batteries, disconnect power terminals on the F/R contactors, check the resistance across N.C. power terminals of the reverse contactor. If not 0 ohm, change the reverse contactor. If 0 ohms, switch to forward and check the resistance across the forward N.O. power terminals. If not 0 ohms, change the forward contactor.

REVERSE ONLY

On a SEPEX motor control, check the forward signal input on the controller.

On a series wound motor control, a bad forward contactor is the most probable cause of the problem. Switch to forward and check the voltage on the forward control wire. If not B+, replace the F/R switch. If B+, turn off the key switch, disconnect batteries, disconnect power terminals on the F/R contactors, check the resistance across N.C. power terminals of the forward contactor. If not 0 ohm, change the forward contactor. If 0 ohms, switch to reverse and check the resistance across the reverse N.O. power terminals. If not 0 ohms, change the reverse contactor.

TRAVEL AT REDUCED SPEED

Check batteries.

Turn off all switches and disconnect charger. Wear face shield and gloves. Do not disturb any battery connection to avoid sparks. Check the specific gravity of each cell. Cold batteries, highly discharged batteries or dead cells are the most frequent causes of reduced travel speed.

Check potentiometer.

Turn off the key switch, disconnect potentiometer terminals. Check the resistance between terminals.

Other causes of lower speed:

- dragging brakes;
- cold temperature (higher differential oil viscosity).

INTERMITTENT OPERATION

A bad potentiometer is the most probable cause of the following:

- acceleration is not constant;
- maximum speed is erratic;
- sudden stop after a bump or shock;
- erratic starts, requiring several pedal cycles.

A bad F/R contactor is also a probable cause of the following:

- sudden stop after a bump or shock;
- would not start to move at times.

Erratic starts could also be the cause of a misadjusted potentiometer or micro-switch; the pot signal must be less than 50 ohms when the micro-switch turns on.

PMC has an HPD safety feature that prevents the vehicle from moving if the accelerator pedal is depressed before the key switch is ON and seat switch is activated.

PMC may also have an SRO safety feature that prevents the vehicle from moving if the F/R switch is activated before turning on the key switch and activating the seat switch.

The vehicle stops on a steep and long ramp or while towing a heavy load: the circuit breaker has open to prevent motor overheating and will reset automatically after one minute. The PMC is also equipped with an internal thermal protection that cutback the current until the PMC has cooled down.

NO MOTION

Make sure that the PMC surface is clean and dry; check the terminal areas. Dust Particles or acid contamination, can create current leaks and cause a PMC malfunction.

Check F/R switch

Turn on the key switch and set to forward. Check voltage between the forward terminal and the – terminal on the battery gage, check voltage between the reverse terminal and the – terminal on the battery gage; if both B+, replace the F/R switch.

Check switches and wiring

Disconnect control terminals on the PMC and check all control signals. If a switch pin does not read B+, check wiring or replace the switch.

Check potentiometer

Turn the key switch to OFF, disconnect potentiometer terminals. Check the resistance across terminals: if not within the recommended limits, adjust or replace the potentiometer. Check for shorts between potentiometer wires and vehicle frame; resistance should read at least 1 megohm.

Check main contactor or solenoid

Check voltage across power terminals; if not B+, check circuit breaker or replace the solenoid.

Turn to on the key switch and activate the seat switch. Check voltage across the coil terminals; if not B+, check wiring and interlock switches. Check resistance across power terminals; if not 0 ohms, replace the solenoid.

Check circuit breaker and SEPEX DIODE

Before replacing the circuit breaker, check for shorts in the power circuit and check the SEPEX diode in the power circuit using a diode tester. If no such instrument is at hand, use an ohmmeter: the reading should be weak in one direction and strong in the other way.

Check the resistance across the circuit breaker. If not 0 ohms, replace the circuit breaker.

Check PMC

First disconnect battery B+ and B-, then PMC B+ and M-. Check the internal diode between B+ and M- terminals using a diode tester. If no such instrument is at hand, use an ohmmeter: the reading should be weak in one direction and strong in the other way. If the internal diode is defective, the PMC must be replaced.

Check the Motor

First disconnect battery B+ and B-, disconnect power terminals and check the motor armature and field for opens.

CURTIS SPEED CONTROLLER 1243

MANUAL

MODEL **1243**
Generation 2

MultiMode™
MOTOR CONTROLLER

© 2002 CURTIS INSTRUMENTS, INC.

DESIGN OF CURTIS PMC 1200 SERIES
CONTROLLERS PROTECTED BY U.S.
PATENT NO. 4626750.

CURTIS

CURTIS INSTRUMENTS, INC.

200 Kisco Avenue
Mount Kisco, NY 10509 USA
Tel: 914-666-2971
Fax: 914-666-2188
www.curtisinst.com

1243GEN2 Manual, p/n 37044
Rev. A: October 2002

WIRING : STANDARD CONFIGURATION

2 — INSTALLATION & WIRING: Controller

for the M8 bolts. The maximum bolt insertion depth below the surface of the bus bar is 1.3 cm (1/2"). Bolt shafts exceeding this length may damage the controller. The torque applied to the bolts should not exceed 16.3 N·m (12 ft-lbs).

Two 1/4" quick connect terminals (**S1** and **S2**) are provided for the connections to the motor field winding.

WIRING: Standard Configuration

Figure 3 shows the typical wiring configuration for most applications. **For walkie applications** the interlock switch is typically activated by the tiller, and an emergency reverse switch on the tiller handle provides the emergency reverse signal.

For rider applications the interlock switch is typically a seat switch or a foot switch, and there is no emergency reverse.




Fig. 3 Standard wiring configuration, Curtis 1243GEN2 controller.

DIAGNOSTICS AND TROUBLESHOOTING

7 — DIAGNOSTICS & TROUBLESHOOTING

7

DIAGNOSTICS AND TROUBLESHOOTING

The 1243GEN2 controller provides diagnostics information to assist technicians in troubleshooting drive system problems. The diagnostics information can be obtained by observing the appropriate display on the handheld programmer, the fault message displayed on the Spyglass gauge, the fault codes issued by the Status LED, or the fault display driven by the controller's fault outputs (Fault 1 and Fault 2). Refer to the troubleshooting chart (Table 7) for suggestions covering a wide range of possible faults.

PROGRAMMER DIAGNOSTICS

The handheld programmer presents complete diagnostic information in plain language. Faults are displayed in the System Faults Menu, and the status of the controller inputs/outputs is displayed in the Monitor Menu.

Accessing the programmer's Fault History Menu provides a list of the faults that have occurred since the fault history file was last cleared. Checking (and clearing) the fault history file is recommended each time the vehicle is brought in for maintenance.

For information on 1311 programmer operation, see Appendix B. If you are using the older 1307 programmer, refer to existing documentation.

SPYGLASS DIAGNOSTICS

The eight-character LCD on the Spyglass displays a continuous sequence of hourmeter, battery state-of-charge, and fault messages.

Fault messages are displayed using the same codes that are flashed by the LED (see Table 8). For example, the LED flashes 3,2 for a welded main contactor:

□□□ □□ (3 , 2)	□□□ □□ (3 , 2)	□□□ □□ (3 , 2)
---------------------	---------------------	---------------------

and the corresponding Spyglass message is:

CODE 32

When a fault message is being displayed, the red Fault LED (labeled with a wrench symbol) flashes to catch the operator's attention.

The LCD also displays a warning when either service timer expires. The service warning is not considered a fault and the red Fault LED does not flash. The word SERVICE is displayed for about 20 seconds on each key-on, after the hourmeter is displayed.

The Spyglass is available in 3-LED and 6-LED models; see Figure 21.

TROUBLESHOOTING CHART


7 — DIAGNOSTICS & TROUBLESHOOTING

Table 7 TROUBLESHOOTING CHART				
LED CODE	PROGRAMMER LCD DISPLAY	FAULT CATEGORY	POSSIBLE CAUSE	FAULT CLEARANCE
0,1	NO KNOWN FAULTS	0	n/a	n/a
1,1	CURRENT SHUNT FAULT	1	1. Abnormal vehicle operation causing high current spikes. 2. Current sensor out of range. 3. Controller failure.	Cycle KSI. If problem persists, replace controller.
1,2	HW FAILSAFE	1	1. Noisy environment. 2. Self-test or watchdog fault. 3. Controller failure.	Cycle KSI. If problem persists, replace controller.
1,3	M- SHORTED	1	1. Internal or external short of M- to B-. 2. Incorrect motor wiring. 3. Controller failure.	Check wiring; cycle KSI. If problem persists, replace controller.
1,4	SRO	3	1. Improper sequence of KSI, interlock, and direction inputs. 2. Interlock or direction switch circuit open. 3. Sequencing delay too short. 4. Wrong SRO or throttle type selected. 5. Misadjusted throttle pot.	Follow proper sequence; adjust throttle if necessary; adjust programmable parameters if necessary.
2,1	THROTTLE WIPER HI	1	1. Throttle input wire open or shorted to B+. 2. Defective throttle pot. 3. Wrong throttle type selected.	When Throttle Wiper High input returns to valid range.
2,2	EMR REV WIRING	1	1. Emergency reverse wire or check wire open.	Re-apply emergency reverse or cycle interlock.
2,3	HPD	3	1. Improper sequence of KSI, interlock, and throttle inputs. 2. Misadjusted throttle pot. 3. Sequencing delay too short. 3. Wrong HPD or throttle type selected. 5. Misadjusted throttle pot.	Follow proper sequence; adjust throttle if necessary; adjust programmable parameters if necessary.
	SRVC TOTAL	3	1. Total maintenance timer expired.	Reset with programmer.
	SRVC TRAC	3	1. Traction maintenance timer expired.	Reset with programmer.
	TOTAL DISABLED	3	1. Total disable timer expired.	Reset with programmer.
	TRAC DISABLED	3	1. Traction disable timer expired.	Reset with programmer.
2,4	THROTTLE WIPER LO	1	1. Throttle pot wire open or shorted to B+. 2. Wrong throttle type selected. 3. Defective throttle pot.	When Throttle Wiper Low input returns to valid range.
3,1	FIELD SHORT	1	1. Main contactor coil shorted. 2. Field winding shorted to B+ or B-. 3. Field resistance too low.	Check contactor coil and field winding; cycle KSI.
3,2	MAIN CONT WELDED	1	1. Main contactor stuck closed. 2. Main contactor driver shorted.	Check wiring and contactor; cycle KSI.
3,3	FIELD OPEN	1	1. Field winding connection open. 2. Field winding open.	Check wiring and cycle KSI.
3,4	MISSING CONTACTOR	1	1. Main contactor coil open. 2. Main contactor missing. 3. Wire to main contactor open.	Check wiring and cycle KSI.

Table 7 TROUBLESHOOTING CHART, <i>cont'd</i>				
LED CODE	PROGRAMMER LCD DISPLAY	FAULT CATEGORY	POSSIBLE CAUSE	FAULT CLEARANCE
4,1	LOW BATTERY VOLTAGE	2	1. Battery voltage < undervoltage cutback. 2. Corroded battery terminal. 3. Loose battery or controller terminal.	When voltage rises above undervoltage cutoff point.
4,2	OVERVOLTAGE	2	1. Battery voltage > overvoltage shutdown limit. 2. Vehicle operating with charger attached.	When voltage falls below overvoltage cutoff point.
4,3	THERMAL CUTBACK	2	1. Temperature >85°C or < -25°C. 2. Excessive load on vehicle. 3. Improper mounting of controller.	Clears when heatsink temperature returns to within acceptable range.
4,4	ANTI-TIEDOWN	3	1. Mode switches shorted to B+. 2. Mode Select 1 "tied down" to select Mode 2 or Mode 4 permanently.	Release Mode Select 1.
	MOTOR HOT	3	1. Field resistance > motor hot setpoint.	When resistance < setpoint.
	MOTOR WARM	3	1. Field resistance > motor warm setpoint.	When resistance < setpoint.

Fig. 21 *Curtis 840 Spyglass, 3-LED and 6-LED models.*

3-LED Spyglass



The **hourmeter LED** lights when the LCD is displaying hourmeter data.

The **BDI LED** lights when the LCD is displaying BDI%. It flashes when BDI% drops to <10%.

The **Fault LED** flashes to indicate an active fault, and the fault code appears on the LCD.

The word **SERVICE** is displayed at key-on if either service timer has expired.

6-LED Spyglass

The three green **BDI LEDs** function as a bargraph showing BDI% between 52% and 100%.


Yellow LED = 36% – 51% BDI.

Red LED steady = 20% – 35% BDI.

Red LED flashing = 0 – 19% BDI.

The **Fault LED** flashes to indicate an active fault, and the fault code appears on the LCD.

The word **SERVICE** is displayed at key-on if either service timer has expired.



LED DIAGNOSTICS

STATUS LED DIAGNOSTICS

A Status LED is built into the 1243GEN2 controller. It is visible through a window in the label on top of the controller. This Status LED displays fault codes when there is a problem with the controller or with the inputs to the controller. During normal operation, with no faults present, the Status LED flashes steadily on and off. If the controller detects a fault, a 2-digit fault identification code is flashed continuously until the fault is corrected. For example, code “3,2”—main contactor welded—appears as:

□□□ □□	□□□ □□	□□□ □□
(3 , 2)	(3 , 2)	(3 , 2)

The codes are listed in Table 8.

Table 8 STATUS LED FAULT CODES		
LED CODES		EXPLANATION
<i>LED off</i>	████████	no power or defective controller
<i>solid on</i>	□	controller or microprocessor fault
0,1	■ □	controller operational; no faults
1,1	□ □	current sensor error
1,2	□ □□	hardware failsafe fault
1,3	□ □□□	M- fault or motor output short
1,4	□ □□□□	static return to off (SRO)
2,1	□□ □	throttle wiper high
2,2	□□ □□	emergency reverse circuit check fault
2,3	□□ □□□	high pedal disable (HPD), or expired timer
2,4	□□ □□□□	throttle wiper low
3,1	□□□ □	contactor driver overcurrent or field winding short
3,2	□□□ □□	main contactor welded
3,3	□□□ □□□	field winding open
3,4	□□□ □□□□	missing contactor
4,1	□□□□ □	low battery voltage
4,2	□□□□ □□	overvoltage
4,3	□□□□ □□□	thermal cutback, due to over/under temp
4,4	□□□□ □□□□	anti-tiedown fault, or overheated motor

Note: Only one fault is indicated at a time, and faults are not queued up. Refer to the troubleshooting chart (Table 7) for suggestions about possible causes of the various faults. Operational faults—such as a fault in SRO sequencing—are cleared by cycling the interlock switch or keyswitch.

PROGRAMMING PARAMETERS – E-300, E-302, E-322 & E-330**! WARNING !**

The owner of this vehicle shall ensure that the service technicians are qualified, properly trained and obey the safety rules and guidelines in OSHA and ANSI B56 regulations, and in this manual.

Before installing and/or programming the PMC, park the vehicle on a flat level surface, lift the wheels off the ground and secure with jack stands of adequate capacity. Don't connect charger.

Programmable controllers must be programmed using the parameter settings in this service manual, before connecting the motor, to avoid sudden vehicle movement and accident.

Do not try to increase motor speed by changing parameter settings in the speed controller; it can cause accident and severe damage to the motor.

VOLTAGE	NOMINAL BATTERY VOLTAGE, IN VOLTS	3
M1 DRIVE C/L	MODE 1 DRIVE CURRENT LIMIT, IN AMPS	250
M2 DRIVE C/L	MODE 2 DRIVE CURRENT LIMIT, IN AMPS	250
M3 DRIVE C/L	MODE 3 DRIVE CURRENT LIMIT, IN AMPS	250
M4 DRIVE C/L	MODE 4 DRIVE CURRENT LIMIT, IN AMPS	250
M1 BRAKE C/L	MODE 1 BRAKING CURRENT LIMIT, IN AMPS	100
M2 BRAKE C/L	MODE 2 BRAKING CURRENT LIMIT, IN AMPS	100
M3 BRAKE C/L	MODE 3 BRAKING CURRENT LIMIT, IN AMPS	100
M4 BRAKE C/L	MODE 4 BRAKING CURRENT LIMIT, IN AMPS	100
M1 ACCEL RATE	MODE 1 ACCELERATION RATE, IN SEC.	3
M2ACCEL RATE	MODE 2 ACCELERATION RATE, IN SEC.	3
M3 ACCEL RATE	MODE 3 ACCELERATION RATE, IN SEC.	3
M4 ACCEL RATE	MODE 4 ACCELERATION RATE, IN SEC.	3
M1 DECEL RATE	MODE 1 DECELERATION RATE, IN SEC.	3.4
M2 DECEL RATE	MODE 2 DECELERATION RATE, IN SEC.	3.4
M3 DECEL RATE	MODE 3 DECELERATION RATE, IN SEC.	3.4
M4 DECEL RATE	MODE 4 DECELERATION RATE, IN SEC.	3.4
THROTTLE DECEL	THROTTLE DECEL, IN SEC.	0.3
M1 BRAKE RATE	MODE 1 BRAKING RATE, IN SEC.	2
M2 BRAKE RATE	MODE 2 BRAKING RATE, IN SEC.	2
M3 BRAKE RATE	MODE 3 BRAKING RATE, IN SEC.	2
M4 BRAKE RATE	MODE 4 BRAKING RATE, IN SEC.	2
INT BRAKE RATE	INT BRAKE RATE, IN SEC.	2
QUICK START	QUICK START THROTTLE FACTOR	0
TAPER RATE	Regen brak. Decrease rate when apporch. 0spd, 1/32s	20
M1 MAX FWD SPD	MODE 1 MAX. FWD SPEED, AS % PWM OUTPUT	40
M2 MAX FWD SPD	MODE 2 MAX. FWD SPEED, AS % PWM OUTPUT	72
M3 MAX FWD SPD	MODE 3 MAX. FWD SPEED, AS % PWM OUTPUT	86
M4 MAX FWD SPD	MODE 4 MAX. FWD SPEED, AS % PWM OUTPUT	100
M1 MAX REV SPD	MODE 1 MAX. REV SPEED, AS % PWM OUTPUT	40
M2MAX REV SPD	MODE 2 MAX. REV SPEED, AS % PWM OUTPUT	40
M3 MAX REV SPD	MODE 3 MAX. REV SPEED, AS % PWM OUTPUT	40
M4 MAX REV SPD	MODE 4 MAX. REV SPEED, AS % PWM OUTPUT	40
CREEP SPEED	CREEP SPEED, AS % PWM OUTPUT	0
THROTTLE TYPE	THROTTLE TYPE	3
THRO. DEADBAND	Thr. Neutral deadband % of 5kohms pot	6
THROTTLE MAX	Thr. Input req'd for 100%PWM %5kohm pot	90
THRTL MAP	THROTTLE MAP, AS %	30
FIELD MIN	MIN. FIELD CURRENT, IN AMPS	7
FIELD MAX	MAX. FIELD CURRENT, IN AMPS	20
FIELD MAP START	Arm. current at wich FIELD MAP takes effect, amps	70
FIELD MAP	Field winding current, as % armature current	50
CURRENT RATIO	CURRENT RATIO:FACTOR OF 1, 2, 4 OR 8	1
M1 RESTRAINT	MODE 1 RAMP RESTRAINT: 1 TO 10	10
M2 RESTRAINT	MODE 2 RAMP RESTRAINT: 1 TO 10	10
M3 RESTRAINT	MODE 3 RAMP RESTRAINT: 1 TO 10	10
M4 RESTRAINT	MODE 4 RAMP RESTRAINT: 1 TO 10	10
LOAD COMP	LOAD COMPENSATION: 0 TO 25	0

6 MPH MAX : disconnect wire MODE-2-B (PIN 9)

8 MPH MAX : disconnect wire MODE-1-A (PIN 14)



HPD	HIGH PEDAL DISABLE (HPD) TYPE	1
SRO	STATIC RETURN TO OFF (SRO) TYPE	1
SEQUENCING DLY	SEQUENCING DELAY, IN SEC.	1
MAIN CONT INTR	MAIN CONTACTOR INTERLOCK: ON OR OFF	ON
MAIN OPEN DELAY	MAIN CONTACTOR DROPOUT DELAY, IN SEC.	1
CONT DIAG	CONT DIAG, ON OR OFF	ON
AUX TYPE	AUXILIARY TYPE, 0 TO 5	0
AUX DELAY	AUXILIARY DRIVER DROPOUT DELAY, IN SEC.	0.0
EMR REV C/L	EMERGENCY REVERSE CURRENT LIMIT, IN AMPS	50.0
EMR REV CHECK	EMERGENCY REV. WIRING CHECK : ON OR OFF	OFF
EMR DIR INTR	EMR DIR INTR: ON OR OFF	OFF
VARIABLE BRAKE	VARIABLE BRAKE : ON OR OFF	OFF
ANTI-TIEDOWN	ANTI-TIEDOWN: ON OR OFF	OFF
POT LOW FAULT	POT LOW FAULT: ON OR OFF	ON
FULL VOLTS	FULL VOLTS: 174 TO 211	204
EMPTY VOLTS	EMPTY VOLTS : 0 TO 211	174
RESET VOLTS	RESET VOLTS: 174 TO 300	210
BATTERY ADJUST	BATTERY ADJUST : 0.1 TO 20.0	20
BDI LOCKOUT	BDI LOCKOUT : ON OR OFF	OFF
BDI DISABLE	BDI DISABLE: ON OF OFF	OFF
ADJ HRS LOW	ADJ HRS LOW: 0 TO 99	0
ADJ HRS MID	ADJ HRS MID: 0 TO 99	0
ADJ HRS HIGH	ADJ HRS HIGH: 0 TO 99	0
SET TOTAL HRS	SET TOTAL HRS: ON OR OFF	OFF
SET TRAC HRS	SET TRAC HRS: ON OR OFF	OFF
HOURLMETER TYPE	HOURLMETER TYPE: ON OR OFF	OFF
SRVC TOTAL HRS	SRVC TOTAL HRS: 0.0 TO 50.0	0.0
SRVC TRAC HRS	SRVC TRAC HRS: 0.0 TO 50.0	0.0
SRVC TOTAL	SRVC TOTAL : ON OR OFF	OFF
SRVC TRAC	SRVC TRAC: ON OR OFF	OFF
DIS TOTAL HRS	DIS TOTAL HRS: 0 TO 250	0
DIS TRAC HRS	DIS TRAC HRS: 0 TO 250	0
TRAC FAULT SPD	TRAC FAULT SPEED: 0 TO 100	100
BDI LIMIT SPD	BDI LIMIT SPEED: 0 TO 100	100
WARM SPD	WARM SPEED : 0 TO 100	100
MOT WARM	MOT WARM X 10 m : 10 TO 250	250
MOT HOT	MOT HOT X 10 m : 10 TO 250	250
MOTOR COMP	MOTOR COMP: ON OR OFF	OFF
MAX REV REGEN	MAX REV REGEN : 100 TO 300	100
MAX FWD REGEN	MAX FWD REGEN: 100 TO 300	100
MIN REV REGEN	MIN REV REGEN: 100 TO 300	25
MIN FWD REGEN	MIN FWD REGEN: 100 TO 300	25
MAX LOAD VOLTS	MAX LOAD VOLTS: 0.2 TO 5.5	0.2
MIN LOAD VOLTS	MIN LOAD VOLTS: 0.2 TO 5.0	0.2
INT BRAKE DLY	INT BRAKE DLY : 0.0 TO 8.0	0.0
FAULT CODE	ON OR OFF	ON
EMR BRAKE PWM	EMR BRAKE PWM : ON OR OFF	OFF
FIELD CHECK	FIELD CHECK: ON OR OFF	ON
PUMP METER	PUMP METER : ON OR OFF	OFF

SPARE PARTS

BODY



<i>REF</i>	<i>PART NO</i>	<i>DESCRIPTION</i>
1	2383320004 1005003	SEAT BUCKET SEAT ON SLIDE ADJUSTERS
2	120003	TRIMMING
3	2314320001	FRONT BUMPER
5	283001	4.80 X 8 PNEUMATIC WHEEL, 5 BOLT
	283002	4.80 X 8 FOAMFILLED WHEEL, 5 BOLT
	2807001	16" O.D. N.M. SOFT WHEEL, 5 BOLT
6	2382320011	BACKREST CUSHION
7	2803300009	LEFT HANDLE
	2809300008	RIGHT HANDLE
8	2352330013	LIFT-OUT BATTERY TRAY

CAB**REF PART NO DESCRIPTION**


1	2360320012	STEEL CAB
	2382320009	SEATBACK CAB
2	2360320014	RIGHT DOOR
	2360320015	LEFT DOOR
	2360320024*	RIGHT DOOR, REAR PASSENGERS
	2360320025*	LEFT DOOR, REAR PASSENGERS
3	2803000003	PADDLE LATCH
	2366320015	DOOR LATCH
4	2365000001	RIGHT HINGES KIT
	2365000002	LEFT HINGES KIT
5	2367320002	RIGHT DOOR GLASS
	2367320001	LEFT DOOR GLASS
	2367320008*	RIGHT DOOR GLASS, REAR PASS.
	2367320007*	LEFT DOOR GLASS, REAR PASS.

REF PART NO DESCRIPTION


6	2801000002	REAR VIEW MIRROR
7	2802000001	TRIM DOOR
8	2801000001	SIDE MIRROR
9	2399000014	SIDE MIRROR BRACKET
10	3113000001	WIPER MOTOR
	2800000002	WIPER
	2800000001	ARM
11	2366320001	DOOR HANDLE
12	2366320002	DOOR HANDLE BAR
13	2366320003	DOOR LEVER
14	2367300001	REAR GLASS
15	2367300002	WINDSHIELD

* 4 or 6 passengers option


DIFFERENTIAL




REF	DESCRIPTION	QTY.	PART NO.
1	Description Housing, Axle, Service (Inc. 1, 2)	1	2171300001
2	Bolt, Bearing Cap	4	2179300001
3	Shaft, input	1	2116300001
4	Ring, Retaining	3	2179300002
5	"O" Ring	3	2104300002
6	Bearing, Ball	1	2102300001
7	Bearing, Ball	1	2102300002
8	Plug, End Cap	2	2179300003
9	Bearing, Ball	2	2102000003
10	Assembly, Gear, Intermediate	1	2116300002
11	"O" Ring	2	2104300003
12	Gear, Final Drive	1	2116300003
13	Bearing, Ball	2	2102000004
14	Assembly, Differential	1	2117300001
15	Bolt, Hex	4	2179000003
16	Nut, Lock	4	2179000004
17	Plate, Cover	1	2179300004
18	Plug, Hex Head	1	2179300005
19	Screw, Tapping	10	2179300006
20	Vent	1	2179000005
21	Screw, Socket Head	8	2179000006
22	Washer, Flat	8	2179000007
23	Nut, Lock	8	2179000008
24	Seal, Oil	2	2104000004
25	Ring, Retaining	2	2179000009
26	Assy, Bearing, Tapered Roller	2	2108000001
27	Seal, Oil	2	2104000005
28	Assembly, Brake (L.H.)	1	2124000001
29	Assembly, Brake (R.H.)	1	2124000002
30	Shaft, Axle (L.H.)	1	2173300003
31	Shaft, Axle (R.H.)	1	2173300005
32	Bolt, Wheel	10	2179000010
33	Drum, Brake, Finished	2	2123000001
34	Gasket	1	2807300001
35	Seat, Spring	2	2174000001
36	Kit, Input Gear (Inc. 3, 4, 5, 6, 7)	*	2116300004
37	Kit, Internal Gears (Inc. 3, 10, 12)	*	2116300005
38	Kit, Ball Bearings (Inc. 6, 7, 9, 13)	*	2102300005
39	Kit, Carrier Cover Assy (Inc. 17, 18)	*	2179300007
40	Kit, Assy, Shaft & Bolt (L.H.) (Inc. 30, 32)	*	2173300002
41	Kit, Assy, Shaft & Bolt (R.H.) (Inc. 31, 32)	*	2173300004

HYDRAULIC DRUM BRAKES

REF	PART NO	DESCRIPTION
1	362841	PLATE-CYLINDER
2	362842	BRAKE SHOE
4	362844	SPRING
5	362845	SPRING
6	362846	SPRING
7	362847	SPRING
8	362848	FITTING
9	362849	BLEEDER
10	362850	PISTON
13	362853	ADJUSTER
14	362855	BOLT (GRADE 8)
15	3612001	LEFT LEVER
	3612002	RIGHT LEVER
N/A	2123000001	DRUM – DANA HOUSING
N/A	2123360001	DRUM – GM HOUSING

HYDRAULIC BRAKE CONTROLS


REF	PART NO	DESCRIPTION	QTY	REF	PART NO	DESCRIPTION	QTY
1		Hexagonal nut 1/4-NC		15	2910000014	Clevis pin 5/16 x 3/4	
2	2910000015	Yoke	2	16	2910000016	Yoke	
3		Lock washer 1/4		17		Cotter pin 3/32 x 1	5
4	2930000012	Lubrication fitting	1	18		Flat washer 5/16	1
5	2131100002	Rubber	1	19	2910000007	Clevis 5/16 x 1-1/2	1
6	2131360002	Lever	1	20	2130330001	Handbrake pulling plate	1
7	2133280001	Push rod-master cylinder	1	21	2139240002	Handbrake lever	1
8		Hexagonal nut 3/8-16 NF		22	2129000003	Handbrake cable	2
9	2132320001	Pivot	2	23	2129000001	Clip	2
10		Included with #212500001		24	2910000013	Yoke	2
11	2125000001	Master cylinder	1	25	2921000001	Cable stop	2
12	2910000028	Clevis pin 3/8 x 1-3/32	1				
13		Cotter pin 3/32 x 1					
14	2190000003	Spring	1				



REF	PART NO	DESCRIPTION	REF	PART NO	DESCRIPTION
1	2100300002	BUSHING	40	2208240002	COVER
	2100300001	BUSHING WITH OIL SEAL	41	2219250001	SPACER
2	2100300003	BUSHING	42	2224280001	HUB
3	2103250001	THRUST BEARING	43	2224300002*	HUB
4	2103300001*	TAPER BEARING	44	2229300001	DUST CAP
5	2103300002*	TAPER BEARING	45	2229300002*	OIL SEAL
6	2103300007	TAPER BEARING	46	2229300003*	SPINDLE WASHER
7	2104300004	OIL SEAL	47	2910000005	NUT, LEFT HAND
8	2104300005	OIL SEAL	48	2910000006	NUT, RIGHT HAND
9	2117250001	GEAR	49	2910000017*	BOLT, LONG
10	2120236001*	DISC	50	2910000018*	BOLT, SHORT
11	481431*	RIGHT CALIPER	51	2910000019*	WHEEL NUT
	481430*	LEFT CALIPER	52	2910000020	LOCK WASHER 7/8
12	2121000005*	BUSHING, LONG	53	2910000021	JAM NUT 7/8-NF
13	2121000006*	BUSHING, SHORT	54	2910000022	JAM NUT 3/4-NF
14	2122300001*	LEFT CALIPER SUPPORT	55	2910000023	SPRING PIN ¼ X 1 3/4
	2122300002*	RIGHT CALIPER SUPPORT	56	2910000024	SET SCREW 5/16-NC
15	2128280001*	PADS	57	2910000025	WHEEL BOLT
16	2128280001*	PADS	58	2910300001	CASTELLATED NUT 3/4-NF
17	2129000001*	CLIP	59	2910300002	CASTELLATED NUT 1-UNEF
18	2134000001*	FLEX. HOSE	60	2914364001	BUSHING
19	2139000001*	CALIPER PROTECTOR	61	2916000001	U-BOLT
20	2139000002*	WASHER	62	2930000012	GREASE FITTING
21	2139000003*	BOLT	63**		BOLT 3/8-NC X 1 ½
22	2180240001**	SHOCK ABSORBER	64		BOLT 5/8-NC X 4
23	2182320001	SHACKLE LINK	65		BOLT 5/16-NC X 1 1/4
24	2185320001	PLATE	66		BOLT 5/16-NC X 1
25	2185488001**	PLATE	67		BOLT 7/16-NC X 2
26	2192280001	LEAF SPRINGS	68		CARRIAGE BOLT 1/4-NC X 3/4
27	2200300002	TUBE	69		FLAT WASHER 1/4
28	2200300003	SHAFT	70	2910000042	FLAT WASHER 12mm
29	2201320007	LEFT SPINDLE	71		FLAT WASHER 7/16
	2201360001*	LEFT SPINDLE, BRAKES	72		COTTER PIN 3/16 X 2
30	2201320001	AXLE BEAM	73		COTTER PIN 7/64 X 2
31	2201300007	RIGHT SPINDLE	74*		MACHINE SCREW 1/4-NC X 3/8
	2201360002*	RIGHT SPINDLE, BRAKES	75		NYLON NUT 5/8-NC
32	2205250001	KING PIN	76		LOCK WASHER 1/4
33	2206300003	STEERING SUPPORT, BOLT PATTERN 2 3/8"	77		LOCK WASHER 5/16
	2206320001	STEERING SUPPORT, BOLT PATTERN 2 1/4"	78**		LOCK WASHER 3/8
			79		LOCK WASHER 7/16
34	2207000001	ROD END, LEFT HAND	80	2910000041	HEAVY NUT 1/2-NF
35	2207000002	ROD END, RIGHT HAND	81		NUT 1/4-NC
36	2207300006	REAR TIE ROD	82**		NUT 3/8-NC
37	2207320001	FRONT TIE ROD	83		NUT 5/16-NC
38	2207320009	ARM			
39	2208240001	STEERING WHEEL			

* Front axle with hydraulic disc brakes

** Front axle with shock absorber

MOTOR AND DRIVE**COMMON PARTS**


REF	DESCRIPTION	PART #	REF	DESCRIPTION	PART #
1	PULLEY	262424	8	MOTOR BASE, FORD	Contact manuf.
2	V BELT	242431		BELT TENSIONER	2156000012
3	PULLEY	3651001	9	SEAL	484001
4	BELT, EAGLE	3651002	10	BEARING	484003
5	MOTOR BASE, GM	Contact manuf.	11	SNAP RING	484004
6	BELT TENSIONER, LONG	2156000001	12	NUT WASHER PACK	484006
	BELT TENSIONER, SHORT	2156000007	15	WAVY WASHER	484013
7	PIVOT	2155000001	19	HEADBAND	484015
				EE HEADBAND KIT	A91-107A

SPECIFIC

REF	DESCRIPTION	A89	B98	A00	D00 SEPEX	DC3 SEPEX	DD4 SEPEX	D&D SEPEX
	MOTOR ASS'Y	484000	204050	2450002*	2450003*	3112210001*	3112230001	3112248001
13	BRUSH SPRING	484010	484010	2450006	2450006	2450006	2450006	
14	BRUSH PLATE	484011	484011	2450007	2450007	2450007	2450007	
16	LEAD ASSY.	484017	484017	N/A	N/A	N/A	N/A	
17	BRUSH	484009	484009	N/A	N/A	N/A	N/A	
18	LEAD AND BRUSH ASSY.	N/A	N/A	3112210004	3112210004	3112210004	3112210004	
20	DRIVE ENDHEAD	484002	484002	484002	484002	484002	N/A	
21	COMMUTATOR ENDHEAD	484014	484014	2450009	2450009	2450009	3112230003	
22	ARMATURE & FAN ASSY	484005	484005	2450004	2450004	3112210002	3112230002	
	FAN	484016	484016	484016	484016	484016	N/A	

* WHEN EQUIPPED WITH ELECTROMAGNETIC BRAKE, PLEASE CONTACT THE MANUFACTURER

REAR SUSPENSION AND BRAKE



REF	PART NO	DESCRIPTION
1	2120236001	DISC
2	481431	RIGHT CALIPER
	481430	LEFT CALIPER
3	2121000005	BUSHING, LONG
4	2121000006	BUSHING, SHORT
5	2122236001	MOUNTING PLATE, CALIPER
6	2122300001	LEFT CALIPER SUPPORT
	2122300002	RIGHT CALIPER SUPPORT
7	2128280001	PADS
8	2128280001	PADS
9	2129000001	CLIPS
10	2134000001	FLEX. HOXE
11	2139000002	WASHER
12	2139000003	BOLT
13	2182320002	SHACKLE LINK
14	2185280001	FORD PLATE or
	2185320002	GM PLATE
15	2185320001	DANA PLATE
16	2185320002	GM PLATE
17*	2192280001	4 - LEAF SPRINGS
18**	2192320001	5 - LEAF SPRINGS
19***	2192320002	7 - LEAF SPRINGS, HEAVY DUTY
20	2910000017	BOLT, LONG
21	2910000018	BOLT, SHORT
22	2916000002	U-BOLT 1/2-NF X 2" I.D.
23	2916320001	U-BOLT 1/2-NF X 2 3/4" I.D. or
	2916280003	U-BOLT 1/2-NF X 3 1/4" I.D.
24	2916320001	U-BOLT 1/2-NF X 2 3/4" I.D.
25	2916480001	U-BOLT 1/2-NF X 4" I.D. or
	2916280003	U-BOLT 1/2-NF X 3 1/4" I.D.
26		BOLT 5/8-NC X 4
27	2910000042	FLAT WASHER 12mm
28		MACHINE SCREW 1/4-NC X 3/8
29		NYLON NUT 5/8-NC
30	2910000041	HEAVY NUT 1/2-NF
31	2183240002	BUSHING


* E-302 & 348

** E-320, 322, 330, 360 & 480

*** STANDARD, E-500 & 660 AND OPTIONAL, E-320, 322, 330, 360 & 480


NEW FORD HOUSING: NEED THE LEAF SPRING PLATE 2185320002 AND
U-BOLT 1/2-NF X 3 1/4" I.D. 2916280003.

ELECTRICAL DIAGRAM – SEPEX MAIN CIRCUIT **DIAGRAMME ÉLECTRIQUE – CIRCUIT PRINCIPAL SEPEX**



MOTREC INC.	
SUBJECT:	SEPEX 1243 WITH CHARGER
TITLE:	MAIN CIRCUIT SEPEX
VERSION:	01
DATE:	2010-10-18
AUTHOR:	J. GAGNON
APPROVED:	
DRAWING #:	SEPEX 1243 - CHARGER.VSD

ACCESSORIES – NO DC/DC CONVERTER
ACCESSOIRES – SANS CONVERTISSEUR DC/DC




MOTREC INC.	
SUBJECT:	ACC - 2HL2TL1SL1WM
TITLE: ACCESSORIES - NO DC/DC CONVERTER	
VERSION: 01	DATE: 2006-04-06
AUTHOR: J. GAGNON APPROVED:	
DRAWING # ACC - NO DC-DC - 2HL2TL1SL1WM VSD	


* Accessories ground is connected at an intermediate post relative to vehicle battery set positive post when DC-DC converter option is not taken.
The relative voltage is either 12V or 24V depending on accessories

ACCESSORIES – DC-DC CONVERTER

ACCESSOIRES – CONVERTISSEUR DC-DC



MOTREC INC.	
SUBJECT:	ACC - 2HL2TL1SL1WM
TITLE:	ACCESSORIES – DC/DC CONVERTER
VERSION:	01
DATE:	2005-04-27
AUTHOR:	J. GAGNON
APPROVED:	
DRAWING #:	ACC - DC-DC - 2HL2TL1SL1WM/VSD



MOTREC INC.	
SUBJECT:	OPTIONS - FLASHERS, HEATER & INTERLOCK AC RELAY
TITLE: OPTIONS	
VERSION:	01
DATE:	2009-08-21
AUTHOR:	B. FILTEAU
DRAWING #:	OPTIONS - FLASHERS, HEATER & INTERLOCK AC RELAY (SD)

PARTS LIST

NO	DESIGNATION	REF	QTY
A1	SEPEX SPEED CONTROL	1243-4320	1
B1	STROBE LIGHT	*	1
B2	HORN	*	1
B3	REVERSE ALARM	*	1
E1.A,B	HEADLIGHT	*	2
E2.A,B	TAIL/BRAKE LIGHT	*	2
E3.A,B	AMBER FRONT LIGHT	*	2
F1.A,B,C	FUSE, 15A	246108K	3
F3	CIRCUIT BREAKER, 150A	3107000002	1
F5	DIODE BRIDGE	3669027	1
F6	FUSE, 30A	4890028	1
G1	BATTERY		1
G2	BATTERY CHARGER		1
K1	FLASHER RELAY (INCANDESCENT)	3069004	1
	FLASHER RELAY (LED)	3127000002	1
K2	110 VAC RELAY	366213	
	RELAY BASE	246216	
	RELAY RETAINING CLIP	246216C	
M2	SEPEX MOTOR		1
M4	WIPER MOTOR	*	1
M7	CAB HEATER	*	
P1	INDICATOR (BDI), HOUR METER	*	1
R1	ACCELERATOR	2142100001	1
	PLASTIC GEAR	367015	1
	MICROSWITCH	3109100001	1
	POTENTIOMETER	367003	1
	SPRING	2462008	1
S1	KEY SWITCH	246205	1
S3	SEAT SWITCH	3109000003	1
	CONNECTOR	3109000004	
S7	FORWARD/REVERSE SELECTOR	266211	1
S8	LIGHT SWITCH, ROCKER TYPE	1269004	1
	LIGHT SWITCH, PUSH/PULL	486002	1
S10	HORN BUTTON	*	1
S12	BRAKE LIGHT SWITCH	246207	1
S13	FLASHER SWITCH	*	1
S15	EMERGENCY PUSH BUTTON	3109800001	1
	EMERGENCY PUSH BUTTON LABEL	3109800006	1
U1	DC-DC CONVERTER	*	1
X1	HOUR METER CONNECTOR		1
X3	SPEED CONTROL CONNECTOR		1
X5	BATTERY CHARGER CONNECTOR		1
X29	PVC GROUNDING PLUG, YELLOW	80003	
Y1	MAIN CONTACTOR	3104236001	1
Y10	HEATER SOLENOID	246101	1
	STATIC STRAP	2450001	1

* Consult Motrec illustrated parts


BATTERY CONFIGURATIONS - 36V CONFIGURATIONS DES BATTERIES – 36V

E-280B LIFT-OUT

E-320

E-330


E-360




E-300

E-302


E-322




E-276




E-266



E-266 ROLL-OUT




BUILT-IN CHARGER MODEL 6430-00



Parts list for LESTRONIC II charger MODEL 06430
TYPE 36LC25-8ET 115 VAC 60 Hz

PART NO	DESCRIPTION
07335S	CASE ASSEMBLY
18687S	CASE ASSEMBLY, WITH NO HANDLE
09691S	TRANSFORMER ASSEMBLY
02390S	CAPACITOR, 6.0 MFD, 660 VAC
16354S	HEATSINK ASSEMBLY, WITH DIODES
08776S	FUSE ASSEMBLY
04127S	AMMETER, 0-30 AMP
09685S	ELECTRONIC TIMER ASSEMBLY (RELAY - 04484S)
04484S	RELAY, TIMER KIT, 36 VDC
02028S	BUSHING, 7W-2, INSULATOR FOR DC CORD
02506S	CORDSET, AC, 14/3, 72"
11327S	CORDSET, AC, 14/3, 18"
13895S	CORDSET, AC, 14/3, 114"
08512S	CORDSET, DC, NO PLUG, 12/2, 108"
12781S	CORDSET, DC, GREY RUBBER PLUG, 12/2, 108"
09522S	CORDSET, DC, NO PLUG, 2 #10 AWG, 160"
08020S	CORDSET, DC, WITH LESTER PLUG
08607S	CORDSET, DC, WITH 50 AMP ANDERSON PLUG
08224S	CORDSET, DC, WITH 175 AMP ANDERSON PLUG
11328S	CORDSET, DC, WITH RING TERMINALS
08313S	PLUG ASSY, DC, 50 AMP ANDERSON PLUG
02957S	PLUG ASSY, DC, 175 AMP ANDERSON PLUG
04328S	RECEPTACLE, MOTOR BASE, 125/15

PORTABLE CHARGER MODEL 07710-02




Parts list for LESTRONIC II charger MODEL 07710
TYPE 36LC25-8ET 115 VAC 60 Hz

PART NO	DESCRIPTION
07377S	CASE ASSEMBLY
07849S	TRANSFORMER ASSEMBLY
02390S	CAPACITOR, 6.0 MFD, 660 VAC
16354S	HEATSINK ASSEMBLY, WITH DIODES
08776S	FUSE ASSEMBLY
04127S *	AMMETER, 0-30 AMP
16369S **	AMMETER, 0-30 AMP
06357S	ELECTRONIC TIMER ASSEMBLY (RELAY – 04484S)
04484D	RELAY, TIMER KIT, 36 VDC
02028S	BUSHING, 7W-2, INSULATOR FOR DC CORD
11923S	CORDSET, AC
09522S	CORDSET, DC, 2-#10 AWG, 160", NO PLUG
08512S	CORDSET, DC, NO PLUG
08020S	CORDSET, DC, WITH LESTER PLUG
12781S	CORDSET, DC, WITH GREY LESTER PLUG
08607S	CORDSET, DC, WITH 50 AMP ANDERSON PLUG
08224S	CORDSET, DC, WITH 175 AMP ANDERSON PLUG
10536S	CORDSET, DC, WITH 130" 50 AMP & EZ GO PLUG
08313S	PLUG ASSY, DC, 50 AMP ANDERSON PLUG
02957S	PLUG ASSY, DC, 175 AMP ANDERSON PLUG

* For use with chargers built before Dec. '90


** For use with chargers built after Dec. '90

BUILT-IN/PORTABLE 40A CHARGER



Parts list for LESTRONIC II charger MODEL 09475
TYPE 36LC40-8ET 115 VAC 60 Hz

PART NO	DESCRIPTION
09477S	CASE ASSEMBLY
09476S	TRANSFORMER ASSEMBLY
09041S	HEATSINK ASSEMBLY, WITH DIODES
08849S	DIODE ASSEMBLY
16823S	AMMETER
09685S	ELECTRONIC TIMER ASSEMBLY
02390S	CAPACITOR, 6.0 MFD, 660 VAC
02008S	BUSHING, 8P-2, INSULATOR FOR DC CORD
02028S	BUSHING, 7W-2, INSULATOR FOR AC CORD
02506S	CORDSET, AC
08511S	CORDSET, DC, NO PLUG
18771S	CORDSET, DC, WITH MOLDED PLUG, GREY
08067S	CORDSET, DC, WITH LESTER PLUG
08069S	CORDSET, DC, WITH 50 AMP GREY PLUG
08329S	CORDSET, DC, WITH 175 AMP GREY PLUG
20331S	CORDSET, DC, WITH 175 AMP YELLOW PLUG
09434S	CORDSET, DC, WITH 350 AMP GREY PLUG
08313S	PLUG ASSY, DC, 50 AMP ANDERSON PLUG
02957S	PLUG ASSY, DC, 175 AMP ANDERSON PLUG
08774S	FUSE ASSEMBLY

BUILT-IN/PORTABLE CHARGER MODEL 16360-40

Parts list for MODEL 16360-40
 TYPE 36EL20-8ET
 100-125 or 200-250 VAC / 50-60 Hz

PART NO	QTY.	DESCRIPTION
20952S	1	CASE ASSEMBLY
16365S	1	TRANSFORMER ASSEMBLY
16369S	1	AMMETER
20919S	2	HEATSINK ASSEMBLY, W/ SCR
20948S	2	SCR ASSEMBLY
21475S	1	ELECTRONIC TIMER ASSEMBLY
19233S	1	CONTROL CABLE ASSEMBLY
02028S	1	BUSHING, INSULATOR, 7W-2, FOR DC CORDSET
03894S	1	BUSHING, INSULATOR, 7K-2, FOR AC CORDSET
20916S	1	CORDSET, AC, 16/3, 80", MOLDED PLUG
20924S	1	CORDSET, DC, 12/2, 108", SB-50 PLUG, GRAY
20914S	1	CORDSET, DC, 12/2, 108", SB-50 PLUG, RED
20926S	1	CORDSET, DC, 12/2, 108", SB-175 PLUG, RED
21912S	1	CORDSET, DC, 12/2, 108", SB-175 PLUG, GRAY
21408S	1	CORDSET, DC, 12/2, 108", NO PLUG
05322S	2	FUSEHOLDER
15029S	2	FUSE, 12 AMP, MDA-12
20917S	1	SWITCH ASSEMBLY
18696S	1	SHUNT, ELECTRONIC
14092S	1	CIRCUIT BREAKER, 40 AMP

DELTA-Q HF CHARGER

NO	DESCRIPTION	PART NO		
		BUILT-IN	PORTABLE WITH SB-50	PORTABLE WITH SB-350
1	24V CHARGER (U.S. BATTERY)	3102240002	3102240009	3102240013
	24V CHARGER (LIFELINE BATTERY)	3102240003	3102240010	3102240014
	24V CHARGER (GEL 180AH BATTERY)	3102240004	3102240011	3102240015
	24V CHARGER (27TM BATTERY)	3102240005	3102240012	3102240016
	36V CHARGER (U.S. BATTERY)	3102302001	3102302004	3102302007
	36V CHARGER (LIFELINE BATTERY)	3102302002	3102302005	3102302008
	36V CHARGER (GEL 180AH BATTERY)	3102302003	3102302006	3102302009
	48V CHARGER (U.S. BATTERY)	3102480002	3102480005	3102480008
	48V CHARGER (LIFELINE BATTERY)	3102480003	3102480006	3102480009
	48V CHARGER (GEL 180AH BATTERY)	3102480004	3102480007	3102480010
	72V CHARGER (U.S. BATTERY)	3102720001		
2	CONNECTOR C13	3119000011		
*	PORTABLE CHARGER AC CORD		3120000001	3120000001
*	BUILT-IN CHARGER AC CORD	3120000002		
*	CORDSET, YELLOW PLUG & SB-50G		3120000003	

* NOT ILLUSTRATED



HF/IFPC Battery Charger

Product Manual for:**QuiQ 912-24xx | 36xx | 48xx | 72xx**

Unit 3 – 5250 Grimmer St.
Burnaby, BC, Canada V5H 2H2
Tel: 604.327.8244 Fax: 604.327.8246
www.delta-q.com

SAVE THESE IMPORTANT SAFETY INSTRUCTIONS



This manual contains important safety, operating, and installation instructions – read before using charger.

Battery Safety Information

Warning: Use charger only on battery systems with an algorithm selected that is appropriate to the specific battery type. Other usage may cause personal injury and damage. Lead acid batteries may generate explosive hydrogen gas during normal operation. Keep sparks, flames, and smoking materials away from batteries. Provide adequate ventilation during charging. Never charge a frozen battery. Study all battery manufacturers' specific precautions such as recommended rates of charge and removing or not removing cell caps while charging.

Electrical Safety Information

Danger: Risk of electric shock. Connect charger power cord to an outlet that has been properly installed and grounded in accordance with all local codes and ordinances. A grounded outlet is required to reduce risk of electric shock – do not use ground adapters or modify plug. Do not touch uninsulated portion of output connector or uninsulated battery terminal. Disconnect the AC supply before making or breaking the connections to the battery while charging. Do not open or disassemble charger. Do not operate charger if the AC supply cord is damaged or if the charger has received a sharp blow, been dropped, or otherwise damaged in any way – refer all repair work to qualified personnel. Not for use by children.

INFORMATIONS IMPORTANTES DE SÉCURITÉ

Conserver ces instructions. Ce manuel contient des instructions importantes concernant la sécurité et le fonctionnement.

Information de Sécurité de la Batterie

Attention: Utiliser seulement sur les batteries 72V avec un algorithme approprié au type spécifique de batterie – voir le manuel. D'autres types de batteries pourraient éclater et causer des blessures ou dommages. Les batteries peuvent produire des gaz explosifs en service normal. Ne jamais fumer près de la batterie et éviter toute étincelle ou flamme nue à proximité de ces derniers. Fournir la bonne ventilation lors du chargement. Ne jamais charger une batterie gelée. Prendre connaissance des mesures de précaution spécifiées par le fabricant de la batterie, p. ex., vérifier s'il faut enlever les bouchons des cellules lors du chargement de la batterie, et les taux de chargement recommandés.

Information de Sécurité Électrique

Danger: Risque de chocs électriques. Ne pas toucher les parties non isolées du connecteur de sortie ou les bornes non isolées de la batterie. Toujours connecter le chargeur à une prise de courant mise à la terre. Ne pas ouvrir ni désassembler le chargeur – référer toute réparation aux personnes qualifiées. Pas à l'usage des enfants.

Operating Instructions

1. Always use a grounded outlet. When using an extension cord, avoid excessive voltage drops by using a grounded 3-wire 12 AWG cord.
2. The charger will automatically turn on and go through a short LED indicator self-test (Models 912-xx0x will flash all LED's in an up-down sequence and Models 912-xx1x will alternatively flash its LED RED-GREEN) for two seconds. If the charger is connected to battery pack, a trickle current will be applied until a minimum voltage is reached. If the charger is used in an off-board application and the charger is waiting to be plugged into a battery pack, the charging algorithm number will be displayed for 11 seconds (see "Check / Change Charging Algorithm") before ultimately displaying an under-voltage fault (fault disappears when plugged into battery pack).
3. Once a minimum battery voltage is detected, the charger will enter the bulk charging constant-current stage. Models 912-xx0x will display the current to the battery on the bargraph and Model 912-xx1x will flash its LED GREEN off more than on to indicate <80% charge status. The length of charge time will vary by how large and how depleted the battery pack is, the input voltage (the higher, the better), and ambient temperatures (the lower, the better). If the input AC voltage is low (below 104VAC), then the charging power will be reduced to avoid high input currents (Models 912-xx0x 'AC' LED and Models 912-xx1x single LED both flash YELLOW). If the ambient temperature is too high, then the charging power will also be reduced to maintain a maximum internal temperature (Models 912-xx0x bargraph flashes and Models 912-xx1x single LED flashes YELLOW).
4. When the battery is at approximately 80% state of charge, the bulk stage has completed and an >80% charge indication is given (Models 912-xx0x turn on the '80%' LED and Models 912-xx1x will flash its LED GREEN on more than off). In the next phase known as the absorption or constant-voltage phase, the last 20% of charge is then returned to the battery. The charging could be terminated at this point if the vehicle requires immediate usage, however, it is highly recommended to wait until 100% charge indication is given to ensure maximum battery capacity and life.
5. A low current "finish-charge" phase is next applied to return and maintain maximum battery capacity (Models 912-xx0x will flash the "100%" LED).
6. When Models 912-xx0x "100%" LED or Models 912-xx1x single LED is continuously GREEN, the batteries are completely charged. The charger may now be unplugged from AC power (always pull on plug and not cord to reduce risk of damage to the cord). If left plugged in, the charger will automatically restart a complete charge cycle if the battery pack voltage drops below a minimum voltage or 30 days has elapsed.
7. If a fault occurred anytime during charging, a fault indication is given by flashing RED with a code corresponding to the error. There are several possible conditions that generate errors. Some errors are serious and require human intervention to first resolve the problem and then to reset the charger by interrupting AC power for at least 15 seconds. Others may be simply transient and will automatically recover when the fault condition is eliminated. To indicate which error occurred, a fault indication will flash RED a number of times, pause, and then repeat.
 - [1 FLASH] Battery Voltage High: auto-recover
 - [2 FLASH] Battery Voltage Low: auto-recover
 - [3 FLASH] Charge Timeout: the charge did not complete in the allowed time. This may indicate a problem with the battery pack (voltage not attaining the required level), or that the charger output was reduced due to high ambient temperatures.
 - [4 FLASH] Check Battery: the battery pack could not be trickle charged up to the minimum level required for the charge to be started. This may indicate that one or more cells in the battery pack are shorted or damaged.
 - [5 FLASH] Over-Temperature: auto-recover. Charger has shutdown due to high internal temperature which typically indicates there is not sufficient airflow for cooling – see Installation Instructions 1). Charger will restart and charge to completion if temperature comes within accepted limits.
 - [6 FLASH] QuiQ Fault: an internal fault has been detected. If Fault 6 is again displayed after interrupting AC power for at least 15 seconds, the charger must be brought to a qualified service depot.

Maintenance Instructions

1. For flooded lead-acid batteries, regularly check water levels of each battery cell after charging and add distilled water as required to level specified by battery manufacturer. Follow the maintenance and safety instructions recommended by the battery manufacturer.
2. Make sure charger connections to battery terminals are tight and clean.
3. Do not expose charger to oil, dirt, mud or to direct heavy water spraying when cleaning vehicle.

See flip side for **Product Specifications and Installation Instructions** for qualified personnel.

Specifications

DC Output – see Operating Instructions

QuiQ Model: 912-	24xx	36xx	48xx	72xx
Voltage-nom (V)	24	36	48	72
Voltage-max (V)	33.6	50.4	67.2	100
Current-max (A)	25	21	18	12
Battery Type	Specific to selected algorithm			
Reverse Polarity	Electronic protection – auto-reset			
Short Circuit	Electronic current limit			

AC Input

All models	
Voltage-max (Vrms)	85 – 265
Frequency (Hz)	45 – 65
Current-max (Arms)	12A @ 104VAC (reduced 20% <104V)
Current – nominal (Arms)	10A @ 120VAC / 5A @ 230VAC
AC Power Factor	>0.98 at nominal input current

Operation

Charger Model: 912-	xx0x (10 LED)	xx1x (1 LED)
AC ON	Solid YELLOW	LED Active
AC LOW	Flash YELLOW	Flash YELLOW
Thermal Cutback	Flash Bargraph	Flash YELLOW
<80% Charge Indicator	-	Short Flash GREEN
>80% Charge Indicator	Solid YELLOW	Long Flash GREEN
100% Charge Indicator	Solid GREEN	Solid GREEN
Fault Indicator	Flash RED	Flash RED
DC Ammeter	LED Bargraph	-
Bat Temp Compensation	Automatic	Optional
Maintenance Mode	Auto-restart if V<2.1Vpc or 30 days elapse.	

Installation Instructions



WARNING: The output of chargers with greater than 48V may pose an energy and/or shock hazard under normal use. These units must be installed in the host equipment in such a manner that the output cable and battery connections are only accessible with the use of a tool by qualified personnel.

1) Determine Mounting Location:

While its sealed nature allows the charger to be mounted virtually anywhere, the choice of mounting location and orientation is extremely important. For optimum performance and shortest charge times, mount the charger in an area with adequate ventilation. The charger should also be mounted in an area that will be relatively free of oil, dirt, mud, or dust since accumulations within the fins of the charger will reduce their heat-dissipating qualities. Optimal cooling also occurs when the charger is mounted on a horizontal surface with the fins vertical. More airflow from below the charger will help cool the fins, so mounting above open areas or areas with cut-outs for airflow is desirable. Contact Delta-Q for information on other mounting orientations. As the charger may get hot in operation, the charger must be installed such that risk of contact by people is reduced. The charger's AC plug must be located at least 18" above the floor/ground surface and the status display must be visible to the user.

2) Mounting Procedure:

Mount the charger by the mounting plate using appropriate fasteners (i.e. 1/4" or M6 with locking hardware). For UL2202 compliance, a 12AWG green bonding wire with ring terminals must be attached from the bonding stud located on the front of the charger (identified by ) to the vehicle frame. The vehicle connection must be made using corrosion resistant hardware (e.g., a #10 stainless steel machine screw with at least two threads of engagement and, if required, a paint piercing washer).

3) DC Battery Connection Procedure:

- The green wire outputs battery voltage when the charger is not plugged into AC to provide an interlock function – see Fig. 1. If used, a user-supplied 1A fast-blow external fuse must be installed inline to prevent damage. Shorting or drawing more than 1A may damage charger and void the warranty.
- Securely fasten the black ring terminal from the charger to the negative terminal ("–", "NEG", "NEGATIVE") of the battery pack.
- Check that the correct charge algorithm is being used – refer to section 4). Securely fasten the red ring terminal to the positive terminal ("+", "POS", "POSITIVE") of the battery pack.

Mechanical

All models	
Dimensions	28.0 x 24.5 x 11.0 cm (11 x 9.7 x 4.3")
Weight	<5 kg (<11 lbs) w/ standard output cord
Environmental	Enclosure: IP46
Operating Temperature	-30°C to +50°C (-22°F to 122°F), derated above 30°C, below 0°C
Storage Temperature	-40°C to +70°C (-40°F to 158°F)
AC input connector	IEC320/C14 (require ≥1.8m localized cord)
DC output connector	OEM specific w/ 12AWG wire

Regulatory

Safety	
EN 60335-1/2-29	Safety of Appliances/ Battery Chargers
UL2202	EV Charging System Equipment
UL1564 2nd Edition	Industrial Battery Charger
CSA-C22.2 No. 107.2	Battery Chargers- Industrial
Emissions	
FCC Part 15/ICES 003	Unintentional Radiators Class A
EN 55011	Radio disturbance characteristics (Class A)
EN 61000-3-2	Limits for harmonic current emissions
EN 61000-3-3	Limits of voltage fluctuations and flicker
Immunity	
EN 61000-4-2	Electrostatic discharge immunity
EN 61000-4-3	Radiated, radio-frequency, EMF immunity
EN 61000-4-4	Electrical fast transient/burst immunity
EN 61000-4-5	Surge immunity
EN 61000-4-6	Conducted Immunity
EN 61000-4-11	Voltage variations immunity




Figure 1

4) Check / Change Charging Algorithm:

The charger comes pre-loaded with algorithms for batteries as detailed in Table 1. If your specific battery model is not listed, please contact Delta-Q. Each time AC power is applied with the battery pack NOT connected, the charger enters an algorithm select/display mode for approximately 11 seconds. During this time, the current Algorithm # is indicated on the '80%' LED (Models 912-xx0x) or on the single LED (Models 912-xx1x). A single digit Algorithm # is indicated by the number of blinks separated by a pause. A two digit Algorithm # is indicated by the number of blinks for the first digit followed by a short pause, then the number of blinks for the second digit followed by a longer pause.

To check / change the charging algorithm:

- Disconnect the charger positive connector from battery pack. Apply AC power and after the LED test, the Algorithm # will display for 11 seconds.
- To change algorithm, touch positive connector during the 11 second display period to the battery pack's positive terminal for 3 seconds and then remove – the Algorithm # will advance after 3 seconds. Repeat until desired Algorithm # is displayed. A 30 second timeout is extended for every increment. Incrementing beyond the last Algorithm moves back to the first Algorithm. After desired Algorithm # is displayed, touch the charger connector to the battery positive until the output relay is heard to click (~10 seconds) – algorithm is now in permanent memory.
- Remove AC power from the charger and reconnect the charger positive connector to the battery pack. It is highly recommended to check a newly changed algorithm by repeating step 4) above.

Alg #	Battery Type
35	Concorde 2xxAh AGM
27	Crown CR325 dv/dt
26	Deka 8GGC2 Gel
11	generic flooded CP dv/dt
8	Concorde 1xxAh AGM
7	Trojan J305 dv/dt
6	DEKA 8G31 Gel
5	Trojan 30XHS
4	US Battery US2200
1	Trojan T-105

Table 1.

Product warranty is two years - please contact dealer of original equipment for warranty service.

Note: This is a Class A product. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures.

Aug 2006 © Delta-Q Technologies Corp. All rights reserved. PN: 710-00xx Rev 1 V1.16

MOTREC ILLUSTRATED ACCESSORIES

 Strobe light, pole mount Amber 12-80V: 3116000002 Red 12-80V: 2469001 Blue 12-80V: 3690008	 Red Tail/Brake light ** Model EE ** Assembly: 3111000030 Housing: 3111000027 Plug: 3111000029 12V : 3111000028	 Headlight Left: 3111480003 Right: 3111480004 Bulb H/L: 3111480006 Bulb Turn: 3111480008 Bulb Mark: 3111480007	 Red Tail/Brake light 12V: 386002  Red Tail/Turn/Rev light 12V: 3111000002
 Strobe light, cab mount Amber 12-48V: 3116250001 Red 12-48V: 3069026 Blue 12-48V: 3069014 Amber 72-80V: 3116720001 Red 72-80V: 3116720002 Blue 72-80V: 3116720003	 Red Tail/Brake light Housing: 3069012R Bulb 12V: 3117240001	 Headlight Left: 3111480003 Right: 3111480004 Bulb H/L: 3117480001 Bulb Turn: 3117480003 Bulb Mark: 3117480002	 Horn button VIP 2208224002
 Amber turn lamp 12V: 3111000022 Bulb 12V: 3069021 Multi-LED amber turn lamp Round Light: 3111000010 Grommet: 3111000008 Plug: 3111000009	 Back-up lamp Grommet: 3269001 12V: 3669012 24V: 3669012A	 Turn signal switch 246050	 Horn button, column mount 3109000011
 Red Tail/Brake light Grommet: 3269001 Plug: 246012A 12V : 2469021 24V : 2469022	 Clear lamp 12V: 3069012 Bulb 12V: 1269008	 Multi-LED Red Tail/Brake Light: 3111000006 Grommet: 3111000008 Plug: 3119000009	 Horn button, dash mount 266210
	 Pedestal head lamp 12V: 3111240001 Bulb 12V: 2569001B Bulb 24V: 2169001B	 Multi-LED Back-up Light: 3111000007 Strobe light: 3111000013 Grommet: 3111000008 Plug: 3119000009	 Horn button 3109250001  Horn 12V: 246003 24V: 246013

 Analog Voltmeter 12V : 3069007 24V : 2469002 36-48V : 3669002	 Wiper motor 12V: 3113000001 24V: 486211	 Cab heater 12V: 3103300001 36V: 3669008 48V: 4869020	 Headlamp 12V:3111250007
 HOBBS Gauge 24V: 2469026 36V: 3069038 48V: 4869037	 Wiper arm 2800000001	 12V Dome light 3669006	 Headlamp 12V: 3111300001 Bulb 12V: 3111300002
 DC-DC converter, 10A 12-48V: 3069019	 Wiper blade 14" Blade: 2800000002 18" Blade: 2800000003	 12V Fan 3669013	 Red Pilot light 12V: 246212 Bulb 12V: 246212B
 DC-DC Converter, 25A 12-48V: 3124000002 72-80V: 3124880001	 Pantograph wiper arm 246233A	 Limit switch 3109000029	 Back-up alarm or Motion beeper 12-48V : 3100000001 72-80V : 3105720001
 DC-DC Converter, 300W 24V: 3124224001 36-48V: 3124280001 72-80V: 3124880001	 Pantograph wiper blade 246233		 12-24V Adjustable ECCO: 3100000002
 CONNECTOR:3124280002			 12-48V Adjustable PRECO: 3100000004

BATTERY DISCHARGE INDICATOR (HOBBS)

This indicator monitors :

- the residual capacity of batteries;
- operating hours;
- status of service down counter.

The residual capacity of the battery is monitored via an 8-LED bar display. When the left red LED lights, the batteries must be charged to avoid damage. The LED display starts flashing as a pre-warning signal. The lower voltage limit is adjustable via potentiometer “M” on the rear.

A	B	C	D	E	F	G	H	I	J	K
1,57	1,63	1,68	1,73	1,78	1,82	1,84	1,86	1,89	1,91	1,93

In order to activate a new adjustment, the unit has to be reset :

- 2.35V/cell reset voltage with battery remaining in vehicle;
- 2.09V/cell reset voltage after battery has been disconnected.

To maintain a good battery performance, it is recommended to limit the discharging to 80% of the battery capacity. The recommended setting for 6V batteries is F and the recommended setting for an industrial battery is K.

An internal relay can prevent overdischarging and damaging the batteries. The relay can be wired to cut off the reverse direction, or energize an N.C. relay and alarm.

Turning off and on the vehicle will override the protection for 30 sec.

The current status (remaining operating hours before maintenance) of the service down counter is indicated for a period of 5 seconds after the key switch is turned on. When it is down to 0, the display flashes. After the maintenance, reset the counter: depress the button “R” on the rear. The service counter is factory programmable only.

24V UNIT #: 2469026

36V UNIT #: 3069038

48V UNIT #: 4869037

2- Orange, key switch


3- Relay +

4- Relay -

5- Black, battery –

6- Blue, hour counter

8- White, battery +



ADDENDUM

CURTIS FOOT PEDAL

