

T-448HD



WARNING

This manual is for the exclusive use of dealers accredited by Motrec International Inc. and should not be considered an official document constituting any kind of guarantee for the end user. All information and data are subject to change without notice. All photos contained in this document are for illustrative purposes only and may include non-applicable options.

PARTS:

It is recommended that part numbers be confirmed with Motrec International Inc. before ordering by providing the serial number of the vehicle requiring the part. In some cases, the part installed on the vehicle may differ from the manual depending on the options chosen.

Publication date:

July 1, 2015

Edition for vehicles with
a serial number higher than:

1059506

For additional information,
please contact our customer service:

MOTREC INTERNATIONAL INC.

200 Des PME Street
Sherbrooke, Quebec J1C 0R2
Canada
1-866-846-3558

AVERTISSEMENT

Ce manuel est destiné à l'usage exclusif des concessionnaires accrédités par Motrec International Inc. et n'est pas considéré comme un document officiel pouvant servir de garantie pour l'utilisateur final. Les informations et données sont assujetties à des changements sans préavis. De plus, les photos présentées sont à titre indicatif seulement et pourraient inclure des options non applicables.

PIÈCES:

Il est recommandé de valider les numéros de pièces avec Motrec International Inc. avant de commander, en fournissant le numéro de série du véhicule pour lequel la pièce est requise. Dans certains cas, il est possible que la pièce installée sur le véhicule diffère du manuel en fonction des options choisies.

Date de publication:

1^{er} juillet 2015

Édition destinée aux véhicules ayant
un numéro de série supérieur à:

1059506

Pour toutes informations additionnelles,
contactez notre service à la clientèle:

MOTREC INTERNATIONAL INC.

200, rue des PME
Sherbrooke, Québec J1C 0R2
Canada
1-866-846-3558

MOTREC



T-448HD



**OPERATOR AND MAINTENANCE MANUAL
SPARE PARTS LISTS INCLUDED**

SERIAL NUMBER: 1059506 & UP

Printed in Canada

One Year Limited Warranty

Effective April 25, 2005, Motrec International Inc. (MOTREC) hereby warrants to the Original Retail Purchaser (Owner) that any of its vehicles shall be free from any defect in materials for a period of 90 DAYS while in the possession of such Original Retail Purchaser. This warranty IS NOT TRANSFERABLE to any subsequent Buyer.

The warranty period is extended to one year or one thousand (1,000) hours, which ever first occurs, on the electric motor, differential (parts that bathe in oil) and the electronic speed controller. MOTREC makes no warranty or representation with respect to the internal combustion engine, tires and batteries, since their respective manufacturers cover such parts. Accessories (light, gage, horn, etc), electrical contacts (switch, solenoid, contactor, relay), diodes & fuses, belts & pulleys, filters & spark plugs, lubricants, brake linings & shoes, brake drums & discs, seals, seats, trim and other items subject to wear are not included in this warranty; nor is any item that in MOTREC sole opinion, shows evidence of neglect, misuse, abuse, collision or alteration.

This warranty shall not apply to normal maintenance requirements as described in the User Manual, and to damages during shipment. The latter is the carrier's responsibility. No compensation will be allowed for delays.

To initiate warranty coverage on any MOTREC vehicle, the Dealer must complete and return the "Sales/Installation Report" to MOTREC within 30 days after delivery to the Original Retail Purchaser; or within 90 days after the delivery date to the Dealer, which ever occurs first. Failure to follow these procedures will result in considering the warranty coverage effective as of the shipment date from the factory.

The defective vehicle must be returned, at the Owner's expense, to an authorised MOTREC Dealer within 30 days after failure. The Owner will not be charged for parts and labour required for warranty repairs, which must be performed by an authorised MOTREC Dealer only. The vehicle will be returned at the owner's expense. The Warranty Claim Forms must be completed and returned with the defective part(s) to MOTREC within 30 days after repair was done. No compensation will be allowed for damages caused by vehicle downtime.

It is the responsibility of the owner of the vehicle to make sure that the driver is properly trained and instructed in the safety features and operation of the vehicle, including vehicle stability, as required by OSHA and ANSI-B56. Operators shall read, understand and follow the safety and operating instructions in MOTREC Manual before driving the vehicle. Operators shall not be permitted to drive the vehicle unless a complete and adequate training has been provided. Driving a vehicle constitutes a hazard. The driver is responsible for the control of the vehicle while driving and must always evaluate and care for all peculiar situations that he or she may meet while driving. The driver assumes the inherent hazards related to this activity. The vehicle is designed for off-road use only. MOTREC disclaims any liability for incidental or consequential damages, to include, but not be limited to, personal injury or property damage arising from vehicle misuse, lack of maintenance or any defect in the vehicle.

It is the responsibility of the Owner of the vehicle to make sure that the service technicians are properly trained as required by OSHA and ANSI-B56. Service technicians shall read, understand and follow instructions in the MOTREC manual before servicing the vehicle. Only qualified and authorized personnel shall be permitted to maintain, repair, adjust and inspect the vehicle.

MOTREC prohibits, and disclaims responsibility for, any vehicle modification altering the weight distribution and stability, increasing the speed or affecting the safety of the vehicle. Such modifications can cause serious personal injury or property damage for which MOTREC disclaims any responsibility.

For Owners that are located outside North America, the warranty period starts the date of shipment from the factory, and the defective parts must be returned at the Owner's expense to MOTREC prior to warranty repair.

TABLE OF CONTENTS

ONE YEAR LIMITED WARRANTY	2
INSTRUCTIONS	4
SAFETY WARNINGS FOR OPERATORS	5
OPERATING INSTRUCTIONS	6
MAINTENANCE	7
SAFETY WARNINGS FOR SERVICE TECHNICIANS	8
DECALS AND LABELS	10
PERIODIC MAINTENANCE CHECKLIST	11
ACCELERATOR	12
BELT INSTALLATION AND TENSIONING	15
HYDRAULIC & PARKING BRAKES	16
FRONT AXLE AND STEERING	17
BATTERY MAINTENANCE	18
BATTERY CHARGER	20
ELECTRICAL TROUBLESHOOTING	21
CURTIS SPEED CONTROLLER 1244	24
WIRING : STANDARD CONFIGURATION	27
DIAGNOSTICS AND TROUBLESHOOTING	28
TROUBLESHOOTING CHART	29
LED DIAGNOSTICS	30
PROGRAMMING PARAMETERS - E-500-80V & T-448HD	31
SPARE PARTS	32
BODY	33
CAB	34
FORD F-150 DIFFERENTIAL	35
BRAKE CONTROLS	37
FRONT AXLE, SUSPENSION, STEERING, DISC BRAKES	38
TILT STEERING WHEEL	40
MOTOR AND DRIVE	41
REAR SUSPENSION AND BRAKE	42
ELECTRICAL DIAGRAM – SEPEX MAIN CIRCUIT	43
DIAGRAMME ÉLECTRIQUE – CIRCUIT PRINCIPAL SEPEX	43
ACCESSORIES – DC-DC CONVERTER	44
ACCESSOIRES – CONVERTISSEUR DC-DC	44
OPTIONS	45
HYDRAULIC DIAGRAM	47
MOTREC ILLUSTRATED ACCESSORIES	49
ADDENDUM	51
CURTIS FOOT PEDAL	52

INSTRUCTIONS

SAFETY WARNINGS FOR OPERATORS

- FAILURE TO OBEY THE FOLLOWING SAFETY RULES MAY RESULT IN SEVERE INJURY.
- It is the responsibility of the owner of this vehicle to train operators to ensure that they understand the operating characteristics of this vehicle, including training in vehicle stability, and obey the following safety rules and guidelines. Owner shall comply with OSHA and ANSI/ITSDF B56.8 & B56.9 Standards for vehicle use, safety rules, operator training and certification. Do not drive this vehicle unless you are a qualified operator.
- Do not drive this vehicle under the influence of drugs or alcohol.
- Do not drive this vehicle on public roads and highways. This vehicle is designed to be driven in buildings.
- The electrical system of this vehicle will make sparks which can ignite inflammable materials. Never use the vehicle in hazardous areas where there are inflammable materials, explosive dust or fumes in the air.
- Have your vehicle inspected regularly by trained personnel, and cease operation if a malfunction occurs.
- Do not open battery compartment to prevent battery explosion, acid splashing, severe damage to eyes or skin.
- Do not open motor compartment. Keep clear from moving, rotating(wheels, sheaves, etc) or lifting parts.
- Never carry more passengers than number allowed for this vehicle. Wait until all occupants are seated and holding on before moving. Always keep all body parts inside vehicle. Keep both hands on steering wheel.
- Do not exceed the vehicle cargo load capacity and gross trailing weight capacity, rated for flat hard even surface. Different operating conditions such as loose terrain or ramps reduce vehicle capacity.
- Avoid loose, unbalanced or top-heavy loads to keep a good stability and prevent overturn. Do not load cargo that can fall off the vehicle. Do not carry cargo that is longer, wider or higher than this vehicle.
- Always depress slowly the accelerator for smooth acceleration. Avoid stunt driving or horseplay.
- Avoid sharp turns, always slow down before turning, to prevent vehicle overturn or trailer jack knife. Vehicle is more sensitive to overturn and jack knife when traveling on inclines or when carrying a heavy load.
- Always drive straight up and down the face of an incline, never across the face, to prevent overturn and trailer jack knife. Drive slower and start applying brakes sooner on inclines to adjust for longer stopping distance.
- Use extra care and drive slowly in reverse, in congested areas or on wet or slippery ground.
- Keep to the right under normal conditions. Maintain a safe distance from all objects.
- Slow down and sound the horn when approaching a corner or other blind intersections.
- Before leaving the vehicle, park on a level ground flat surface, turn off all switches, set the forward/reverse switch to neutral, set the parking brake, remove the key. Do not park the vehicle on an incline.
- Before battery charging, park the vehicle in a well ventilated area set for. Do not operate it when charging. To interrupt a charging cycle, disconnect the AC plug; disconnecting the DC plug or a battery terminal, or operating the vehicle, could damage the charger and produce a spark, battery explosion and acid splashing.
- Use another driver to steer this vehicle while it is towed. Be sure the driver uses brakes when you slow or stop the towing vehicle. Do not exceed 5 MPH or carry any passenger while towing this vehicle.

OPERATING INSTRUCTIONS

It is the responsibility of the owner of this vehicle to ensure that the operator understands the operating characteristics of this vehicle, and obeys the safety instructions in this manual and ANSI/ITSDF B56.8 & 9 Standards. Do not drive this vehicle unless you are a certified operator as required by OSHA.

BEFORE TURNING ON KEYSWITCH

Set to neutral, set parking brake, check for visible damage, check brake pedal.

AFTER TURNING ON KEYSWITCH

Check safety devices: seat switch, reverse alarm, motion beeper, strobe light, and all other safety devices.

BATTERIES

Never open the battery compartment unless you have received proper training for battery maintenance.

Batteries emit explosive hydrogen gas that can be ignited by a spark or loose terminal. Battery acid causes severe damage to eyes or skin. Flush the contaminated area immediately with water. Park the vehicle in a well ventilated area for battery charging. Most battery chargers come with an electronic control that starts when the charger is plugged and stop when the battery is fully charged. To interrupt the charging cycle, disconnect the AC-plug, do not disconnect the DC plug.

BATTERY DISCHARGE INDICATOR

The green light moves from right to left as batteries are being discharged. When the green light is at the last position on the left the batteries must be recharged. A flashing light warns the operator that further discharge will damage batteries. See HOBBS indicator instructions.

EMERGENCY SAFETY DEVICE

The emergency push button or battery disconnect handle, when present, should only be used in case of emergency. Use the key switch for normal ON/OFF control.

KEYSWITCH

Depress brake pedal and turn the key switch clockwise for on position. Always turn off all switches, set the F/R selector to neutral, set the parking brake, remove the key before leaving the vehicle.

HORN

Depress the horn button on the steering column or handle bar.

F/R SWITCH

Three positions with neutral at center. Depress the front part of the rocker switch for forward direction. Depress the rear part of the rocker switch for reverse direction. Always set switch to neutral, turn off all switches, set the parking brake, remove the key before leaving the vehicle.

ACCELERATOR PEDAL

It is designed for right foot operation only, and controls the speed of the vehicle. Apply slowly.

FOOT BRAKE PEDAL

It is designed for right foot operation only. The brake force is proportional to the pressure on the pedal.

PARKING BRAKE

Pull handbrake lever to apply. Never park the vehicle on an incline. Always turn off all switches, set the F/R selector to neutral, set the parking brake, remove the key before leaving the vehicle.

MAINTENANCE

SAFETY WARNINGS FOR SERVICE TECHNICIANS

FAILURE TO OBEY THE FOLLOWING SAFETY RULES MAIN RESULT IN SEVERE INJURY.

Owner shall comply with OSHA and ANSI/ITSDF B56.8 & B56.9 Standards for vehicle maintenance.

Only qualified and authorized personnel shall be permitted to maintain, repair, adjust and inspect carriers, vehicles, tractors, and batteries.

Before any maintenance work, park the vehicle on flat level surface, turn off all switches, remove key, lift wheels off the ground and secure with jack stands of adequate capacity. Don't connect charger.

Keep clear from moving parts such as tires, sheaves and motor.

Follow the maintenance instructions applicable to the type of repair, maintenance, or service.

Always wear a face shield and gloves when working around batteries.

Before opening the battery compartment, disconnect the charger, turn off all switches and remove the key. Batteries emit highly explosive gases which greatly increase when charging; do not disturb connections or produce sparks around batteries to avoid a battery explosion and acid splashing. Battery acid causes severe damage to eyes or skin. Flush contaminated area immediately with water.

Use insulated tools to avoid sparks that can cause battery explosion and acid splashing.

Use two counteracting tools, double-wrench technique, when disconnecting or tightening terminals on the battery and the speed controller to avoid cracking the terminal or battery post welds.

Before cleaning or replacing a battery, charger, speed controller, contactor, relay, diode, or any other component in the power circuit, always disconnect the charger, turn off all switches, remove the key, wear a face shield and gloves, identify battery polarity and disconnect battery leads, discharge the capacitor in the controller with a 10 ohms, 25 W resistor for a few seconds across B+ and B-.

After cleaning, the power must not be reapplied until terminal areas are thoroughly dry.

On EE-Rated vehicles make sure that the control box is sealed, the static strap makes good contact with the ground, the motor is sealed by bands, the cable protectors are properly installed.

Keep cables and wires clear from mechanical and rubbing action. Make sure that cable insulation is free from cutting or visible damage. Make sure that EE-Rated cable protectors are properly installed.

Before replacing a fuse or circuit breaker, identify the cause of failure and repair.

Programmable controllers must be programmed using the parameter settings in this service manual, before connecting the motor, to avoid sudden vehicle movement and accident.

Do not try to increase motor speed by changing parameter settings in the speed controller; it can cause accident and severe damage to the motor.

SEPEX speed controls are protected by a diode in the power circuit to filter inductive loads in the event of a sudden power interrupt. Some speed controllers require a diode to filter inductive loads on the KSI input. Removing the diodes will cause the speed control failure.

Before resuming maintenance operations, inspect safety warnings stickers and replace any if damage is found and part of the text can't be read.

Check decals and labels, see "DECAL AND LABELS" page.

DECALS AND LABELS


! CAUTION !

The images included in this section depict the decals/markings installed on the vehicle. It is of the utmost importance that these decals/markings remain unaltered and readable. Else, the sticker or the part bearing the marking has to be replaced.

Dashboard security warning label:
5100000002



General security warning label:
5100000001



When an emergency push button is installed, this label is required (located under push button): # 3109800006



When a disconnect handle is installed, this label is required (located in front of handle):
4800012J



Respectively, key switch markings, forward/reverse selector markings and light switch marking:



266211



2819321003



1269004

PERIODIC MAINTENANCE CHECKLIST

REVISION 120110

! WARNING !

Maintenance operations must be made by properly trained service technicians.

- Keep clear from moving parts such as tires, sheaves and motor.
- Check for all EE protections, when applicable, and keep cables and wires clear from mechanical and rubbing action
- Batteries contain sulphur acid that can cause severe burns on skin or eyes.
- When working around batteries, wear acid proof protective equipment: face shield and gloves.
- Use electrically insulated tools to avoid sparks that can cause battery explosion.
- Before any maintenance work, park the vehicle on a flat level surface, turn off all switches, remove the key, lift the wheels off the ground and secure with jack stands of adequate capacity, identify and disconnect battery leads. Don't connect the charger.

CHECK/PERFORM	PERIOD HOURS	DAY	WEEK 20	MONTH 50	QUART. 200	YEAR 1000	2 YEARS 2000
MECHANICAL DAMAGE, OIL LEAKS		X					
REVERSE ALARM, DEADMAN SWITCH		X					
STATIC STRAP, min 2" contact with ground		X					
TIRE PRESSURE, pressure rating on tire			X				
CHECK/FILL BATTERIES, add distilled water to cover plates. Fill to recommended level after batteries have been fully charged.			X				
WARNING DECALS & MARKINGS				X			
EE-Rated CABLE PROTECTORS, SEALED MOTOR, SEALED CONTROL BOX, STATIC STRAP.				X			
MASTER CYLINDER FLUID (DOT 3)				X			
BRAKE PEDAL TRAVEL 2" (50 mm) maximum travel				X			
STEERING FOR PLAY				X			
PARKING BRAKE LEVER requires 65-75 lbs. (30-34 kg) force to apply				X			
BELTS AND PULLEYS -10 lbs (5kg). force for 1/8" (3mm) deflexion; -pulleys alignment, see procedure.					X		
CLEAN/TIGHTEN WIRE TERMINALS					X		
WASH BATTERY TOP WITH WATER					X		
MOTOR BRUSHES FOR WEAR -brushes must exceed holders					X		
ACCELERATOR ADJUSTMENT -1/8" (3 mm) travel to activate micro-switch; -0 to 50 ohms when micro-switch activated; -4500 to 5500 ohms with pedal down.					X		
HYDR. BRAKE LINES FOR LEAK					X		
STEERING ASSEMBLY, as instructed					X		
BRAKE MECHANICAL LINKAGES for wear & play					X		
BRAKE LININGS FOR WEAR 1/16" (2 mm) minimum lining thickness. 6 mm minimum thickness for brake-pulley lining.					X		
LUBRICATE (GREASE EP-2) brake pedal pivots, steering column, ball joints and kingpins.					X		
OIL (SAE 30) LEVEL IN DIFFERENTIAL Before adding oil, check oil seals for leaks.					X		
FRONT WHEEL BEARINGS PLAY					X		
TIGHTEN NUTS/BOLTS, electric terminals; drive; steering; brakes; suspension; body.					X		
REPLACE DIFFERENTIAL OIL(SAE 30)						X	
CLEAN AND RE-PACK FRONT HUBS						X	
SERVICE DIFFERENTIAL, replace the three oil seals, wheel bearings, oil (SAE 30)							X

ACCELERATOR

GEAR

- Remove the cover.
- Backlash between gears must be reduced to a minimum by sliding holder; use locktite 262 to lock the three screws.
- When the plastic gear is fully depressed a small backlash must remain between the gears.
- When the plastic gear is released its rear portion must not exceed the pedal case.


MICRO-SWITCH

The micro-switch must deactivate the on/off solenoid when the accelerator is released; turn the adjusting screw (shown on figure below) to adjust the micro-switch height.

POT

- Remove the terminals 2 and 3 on PMC to measure resistance signal.
- When the micro-switch is activated the signal must be less than 50 ohms. When the front portion of the pedal is fully depressed the signal must be more than 4600 ohms.
- To modify the resistance, turn the adjusting screw to change the micro-switch height (see figure below).

Proceed with the same verifications after the accelerator cover is on and then connect terminals 2 and 3.



FOOT PEDAL FP-6 MAINTENANCE GUIDELINES

FEATURES -

- FP 6 is designed for IP rating 64
 - It can work in dusty atmosphere.
 - It has sealing against splashing and spraying water from all side.
 - We do not recommend low pressure or high pressure washing.

SPECIFICATIONS -

- Pedal high point is pedal free condition
- 1st Microswitch Setting ;
 - a) First micro switch should operate at $3^\circ \pm 1^\circ$ (i.e. between 2° to 4°) from free condition
- Pot setting
 - a) Operate pedal slowly; find reading at which first Microswitch operates.
 - b) Pot resistance reading across pot low and wiper (i.e. black and white) must be within 100 Ω to 400 Ω .
- 2nd Micro switch setting
 - a) 2nd micro switch should operate between 4600 Ω and *pot max* resistance, across *pot low and wiper* (i.e. black and white)

INSTALLATION PROCEDURE

Terminology - "**Pot low**", "**wiper**" and "**pot high**" are pot terminals. (Black, white and red cables respectively) "**Pot max resistance**" is the resistance value across pot low and pot high. (Black and Red cables)

1. MICRO SWITCHES AND POT SETTING

For Foot Pedal FP-6, use pot low and wiper (black and white) for setting micro switches.

- Set Pedal at free condition.
- Adjust pedal at 3° deflection. Set first micro switch to operate about set deflection.
- Adjust pot resistance from high valve to get (100 to 400 Ω) across *pot low and wiper* (i.e. black and white).
- Set 2nd micro switch between 4600 Ω and *pot max* resistance.

CHECK LIST / CAUTION

- Pedal angle must be within 30 +/- 3 degree. Check freeness of pedal.
- Select 'resistance' measurement range in as per requirement on the Multi meter. Minimum resistance between pot low and wiper must be less than 10 ohms. Pot Max Resistance (between pot low and pot high) must be within 4500 to 5500 ohms.
- Confirm that micro switch settings are as per specifications.
- Measure the resistance between each of the seven wires and the housing of the Foot Pedal. It should measure "Infinity"
- Visually check the insulating sleeves are put around the soldered side of all seven cables, and that the sleeves are firmly in place.


YEARLY MAINTENANCE

- Remove cover of Pedal.
- Apply 3 to 5 drops oil on pedal return spring.
- Apply 2 drops oil in the slot of front bush.
- Do not apply oil on shaft from outside. It is of no use, due to sealing on the shaft.
 - i. Oil Specification
 - ii. 20W Motor Oil (Or 3 in one motor oil)
 - iii. 20 stand for weight of motor oil.
 - iv. W Stands for winter grade.

BELT INSTALLATION AND TENSIONING


INSTALLATION

Adjust the sprockets using a straight edge. Slide up the edge on the larger pulley until it contacts the smaller pulley. Properly adjusted pulleys will provide three points of contact. Properly aligned pulleys will provide four points of contact. Tighten setscrews and recheck alignment.



TENSIONING

Check the force F required to provide a deflection of $1/8$ in. If the measured force is less than 15 lbs then lengthen centre distance C .



HYDRAULIC & PARKING BRAKES

Revision 2012-01-10

DRUM BRAKES

Remove brake drums and check lining wear. Replace shoes and springs if the lining thickness is 1/16" (2mm) or less. Turn the brake adjustment to reduce the clearance between lining and drum. Wheels must turn free when the pedal is released.

DISC BRAKES

Check pad linings. Replace pads if lining thickness is 1/16" (2 mm) or less.

PARKING BRAKE

Replace cables and stoppers if cable play exceeds 1/8" (4mm).

Wheels and/or differential pinion must turn freely when the parking brake is released.

On pinion brake, use spacers at pad fixed ends to reduce space between pads and pulley to 1mm.

To install new cables and stoppers:

- insert the new cable through the hand lever end;
- pull the cable out from the brake assembly end;
- insert the stopper on the cable and leave a maximum play of 1mm;
- for a two-cable system, make sure that cable length is the same at hand lever end;
- tighten 1/4-NCx3/4 grade-5 bolt in stopper at 8 LbFt (11NM) torque;
- cable must extend 1.5" (4cm) out of the cable stopper, cut cable excess.

Once cable play has been checked and/or adjusted, turn the knob on the brake lever until a force of 65-75 Lbs or 30-34 kg is required on the handle to set the parking brake. Tighten the locking screw.

BRAKE PEDAL

If the brake pedal becomes soft or spongy, air may have entered the hydraulic system and the brake system has to be bled:

1. fill the master cylinder with brake fluid (DOT-3);
2. bleed front callipers one at a time by having someone applying a steady pressure on the brake pedal, and close the bleeder before allowing the brake pedal to return to up position;
3. fill the master cylinder with brake fluid (DOT-3);
4. bleed rear wheel brakes one at a time, following the same procedure;
5. fill the master cylinder with brake fluid (DOT-3);
6. clean every fitting and line, remove traces of oil;
7. apply a continuous pressure on the brake pedal for about five minutes ;
8. Finally, inspect brake lines and fittings for leaks ;

FRONT AXLE AND STEERING

! CAUTION !

Before maintenance, turn off all switches, set to neutral, set parking brake, remove the key, and raise the front end of the vehicle supporting it with two jack stands of adequate capacity

STEERING INSPECTION

- Check tire inflation pressure, suspension components, tie rods straightness, tie rod ends play (wear), play (wear) in wheel bearings, kingpins and bushings.

REPLACING & ADJUSTING THE STEERING GEAR

- Remove the pitman arm;
- The steering box makes 6.5 turns, center the steering gear (3.25 turns from either side);
- Align the front wheel straight. Install the pitman arm.

TOE-IN ADJUSTEMENT

- With the wheels in straight forward direction, measure the inside (left to right) distance between the front tires, at the front and rear of the tires;
- Turn the rear tie rod until the distances are equal and tighten the two lock nuts on the tie rod.

REMOVING & GREASING OF FRONT HUBS, required once-a-year

- Remove dust cap and cutter pin, unscrew nut, remove hub;
- Inspect bearings and races for wear and replace worn bearings;
- Replace the seal;
- Pack the hub with wheel bearing grease and re-assemble.

ADJUSTING FRONT HUBS

- Tighten spindle nut to 30 ft-lb to seat the bearing and back off the nut to the next slot;
- Install a new cutter pin and the dust cap.

BATTERY MAINTENANCE

! WARNING !

- It is the responsibility of the owner of this vehicle to ensure that the service technicians are properly trained, read and obey the safety rules and guidelines in this manual (ANSI B56).
- Maintenance operations must be made by properly trained service technicians only.
- Before any maintenance work, park the vehicle on a flat level surface, turn off all the switches, set to neutral, remove the key, lift the wheels off the ground and secure with jack stands of adequate capacity.
- Keep charger disconnected while doing any maintenance work.
- Always wear a face shield and scarf when working around batteries.
- Battery emits highly explosive gases; do not produce sparks to avoid battery explosion and acid splashing. Battery acid causes severe damage to eyes or skin. Flush contaminated area immediately with water.
- Use insulated tools to avoid sparks that can cause battery explosion and acid splashing.
- Use two counteracting tools, double-wrench technique, when disconnecting or tightening battery posts.
- Before cleaning or replacing a battery, discharge the capacitor in the controller with a 10 ohms, 25 W resistor for a few seconds across B+ and B-, identify battery polarity and disconnect battery leads.
- After cleaning, the power must not be reapplied until terminal areas are thoroughly dry.

BATTERY LEADS AND CONNECTORS

Check for loose connections, damaged cables, acid spill, loose terminal posts, quarterly.

BATTERY POST CORROSION

If corrosion is present on battery posts, remove the cable connectors, use a wire brush to remove particles, and then clean them with a cloth that has been moistened with ammonia.

ELECTROLYTE LEVEL

Does not apply to sealed battery.

- Disconnect battery connectors on roll-out or lift-out installations.
- Make sure the battery roll-out tray is provided with stops before rolling out.
- Fill with distilled water.
- Daily charged batteries normally require watering once a week. Under watering leads to a shortened battery life. Over watering leads to battery corrosion. Be careful not to overfill any cell to avoid electrolyte to be forced out while charging.
- Fill each cell to plate level with distilled or de-ionized water, before battery charging. When the battery is charged, the fluid expands and can seep out if overfilled. Refill each cell after full charge, when the fluid has expanded to its maximum level.
- Reinstall battery caps before charging.

BATTERY MOUNTING

A loose battery increases damaging effects of vibrations and is more prone to short out.

BATTERY DISCHARGE LIMIT

Discharging below a 20% state of charge cuts down the battery life and the number of cycles available. At 20% state of charge, specific gravity of 6V battery should be 1180; and 1220 for industrial battery.

CHARGING AREA

- Always charge battery in a well ventilated area set for and approved for charging.
- Never leave a charger connected for more than 20 hours.

FREQUENCY OF CHARGE

- When a battery is discharged to its 20% state of charge, it is best to charge immediately.
- Batteries require a low current equalization charge (min 4 hours) at least every week, to equalize battery cells, improve battery performance and life in number of cycles.
- Never leave a charger connected for more than 20 hours.

STORAGE

- Keep the battery from getting cold, it would lose its capacity.
- Let the battery warm up before charging.
- Charge batteries in “stored” vehicles every month.

DEFECTIVE BATTERY

Check specific gravity of each cell; if a cell is shorted, voltage drop may occur only when there is current.

BATTERY CHARGER

! WARNING !

Always unplug the AC and DC electrical cords before attempting any repairs to the charger.

CHARGER DOES NOT TURN ON:

- Dc cord of portable chargers must be disconnected from batteries after every charge to restart;
- Check dc fuse links;
- Check battery voltage at the battery connector;
- Check ac outlet and cordset;
- Replace electronic control ;

RELAY CLOSSES AND TRANSFORMER HUMS BUT AMMETER DOES NOT REGISTER:

- Check dc fuse links;
- Check the continuity of the dc output cord, ammeter, diodes and all connections in the dc circuit;
- Check diodes;
- Check capacitor(rapidely increasing resistance);

SINGLE CHARGER FUSE BLOWS:

- Disconnect and check diodes;

BOTH FUSE LINKS BLOW:

- Check the battery pack and battery connector polarity;
- Disconnect and check diodes.

CHARGER OUTPUT IS LOW:

- Disconnect and check diodes;
- Can be caused by a transformer failure.

AMMETER READS 30 AMPS FOR MORE THAN 30 MINUTES:

- Check the battery pack;

CHARGER DOES NOT TURN OFF:

- Check specific gravity in each battery cell;
- As much as 16 hours may be required to properly charge heavily discharged new or cold batteries;
- Replace electronic control.

AC LINE FUSE OR CIRCUIT BREAKER BLOWS:

- Check ac cordset;
- Check ac line fuse rating;
- Replace electronic control;
- Can be caused by a transformer failure.

ELECTRICAL TROUBLESHOOTING

! WARNING !

Maintenance work must be performed by trained service technicians only.

It is the responsibility of the owner of this vehicle to ensure that the services technicians are properly trained, understand and obey the safety rules and guidelines (ANSI B56).

All service technicians must read and understand the maintenance warning section in this manual.

! WARNING !

Before any maintenance work, park the vehicle on a flat level surface, turn off all switches, remove the key, lift the wheels off the ground, secure with jack stands of adequate capacity, disconnect charger.

Always wear safety glasses.

Batteries emit highly explosive gases that can be ignited by a spark. Before disconnecting a high current terminal, turn off all switches, disconnect battery charger, disconnect batteries.

Keep clear from moving parts such as tires, sheaves and motor.

PMC SELF DIAGNOSTIC

If your PMC comes with a status led, use the flashing code to help troubleshooting.

BATTERY VOLTAGE

Make sure batteries are securely connected. Measure voltage between + and - terminals. We will call this value B+ or full battery voltage.

ACCESSORIES NOT WORKING

- Check the fuses on the batteries and the DC/DC converter.
- Check voltage across + and – terminals on the battery gage; if not B+, check wiring.
- Turn the key switch ON, check voltage between output terminal on the key switch and the - terminal on the battery gage; if not B+, replace the key switch.
- Check voltage across DC/DC converter output terminals; if not 12-Volt, replace the converter.
- Depress the accessory switch, check voltage across accessory terminals. If not 12-Volt, replace the switch. If 12-Volt, replace the accessory.

FORWARD ONLY

On a SEPEX motor control, check the reverse signal input on the controller.

On a series wound motor control, a bad reverse contactor is the most probable cause of the problem.

Switch to reverse and check voltage on the reverse control wire. If not B+, replace the F/R switch. If B+, turn off the key switch, disconnect batteries, disconnect power terminals on the F/R contactors, check the resistance across N.C. power terminals of the reverse contactor. If not 0 ohm, change the reverse contactor. If 0 ohms, switch to forward and check the resistance across the forward N.O. power terminals. If not 0 ohms, change the forward contactor.

REVERSE ONLY

On a SEPEX motor control, check the forward signal input on the controller.

On a series wound motor control, a bad forward contactor is the most probable cause of the problem. Switch to forward and check the voltage on the forward control wire. If not B+, replace the F/R switch. If B+, turn off the key switch, disconnect batteries, disconnect power terminals on the F/R contactors, check the resistance across N.C. power terminals of the forward contactor. If not 0 ohm, change the forward contactor. If 0 ohms, switch to reverse and check the resistance across the reverse N.O. power terminals. If not 0 ohms, change the reverse contactor.

TRAVEL AT REDUCED SPEED

Check batteries.

Turn off all switches and disconnect charger. Wear face shield and gloves. Do not disturb any battery connection to avoid sparks. Check the specific gravity of each cell. Cold batteries, highly discharged batteries or dead cells are the most frequent causes of reduced travel speed.

Check potentiometer.

Turn off the key switch, disconnect potentiometer terminals. Check the resistance between terminals.

Other causes of lower speed:

- dragging brakes;
- cold temperature (higher differential oil viscosity).

INTERMITTENT OPERATION

A bad potentiometer is the most probable cause of the following:

- acceleration is not constant;
- maximum speed is erratic;
- sudden stop after a bump or shock;
- erratic starts, requiring several pedal cycles.

A bad F/R contactor is also a probable cause of the following:

- sudden stop after a bump or shock;
- would not start to move at times.

Erratic starts could also be the cause of a misadjusted potentiometer or micro-switch; the pot signal must be less than 50 ohms when the micro-switch turns on.

PMC has an HPD safety feature that prevents the vehicle from moving if the accelerator pedal is depressed before the key switch is ON and seat switch is activated.

PMC may also have an SRO safety feature that prevents the vehicle from moving if the F/R switch is activated before turning on the key switch and activating the seat switch.

The vehicle stops on a steep and long ramp or while towing a heavy load: the circuit breaker has open to prevent motor overheating and will reset automatically after one minute. The PMC is also equipped with an internal thermal protection that cutback the current until the PMC has cooled down.

NO MOTION

Make sure that the PMC surface is clean and dry; check the terminal areas. Dust Particles or acid contamination, can create current leaks and cause a PMC malfunction.

Check F/R switch

Turn on the key switch and set to forward. Check voltage between the forward terminal and the – terminal on the battery gage, check voltage between the reverse terminal and the – terminal on the battery gage; if both B+, replace the F/R switch.

Check switches and wiring

Disconnect control terminals on the PMC and check all control signals. If a switch pin does not read B+, check wiring or replace the switch.

Check potentiometer

Turn the key switch to OFF, disconnect potentiometer terminals. Check the resistance across terminals: if not within the recommended limits, adjust or replace the potentiometer. Check for shorts between potentiometer wires and vehicle frame; resistance should read at least 1 megohm.

Check main contactor or solenoid

Check voltage across power terminals; if not B+, check circuit breaker or replace the solenoid.

Turn to on the key switch and activate the seat switch. Check voltage across the coil terminals; if not B+, check wiring and interlock switches. Check resistance across power terminals; if not 0 ohms, replace the solenoid.

Check circuit breaker and SEPEX DIODE

Before replacing the circuit breaker, check for shorts in the power circuit and check the SEPEX diode in the power circuit using a diode tester. If no such instrument is at hand, use an ohmmeter: the reading should be weak in one direction and strong in the other way.

Check the resistance across the circuit breaker. If not 0 ohms, replace the circuit breaker.

Check PMC

First disconnect battery B+ and B-, then PMC B+ and M-. Check the internal diode between B+ and M- terminals using a diode tester. If no such instrument is at hand, use an ohmmeter: the reading should be weak in one direction and strong in the other way. If the internal diode is defective, the PMC must be replaced.

Check the Motor

First disconnect battery B+ and B-, disconnect power terminals and check the motor armature and field for opens.

CURTIS SPEED CONTROLLER 1244

MANUAL

CURTISPMC

MODEL **1244**

MultiMode™
MOTOR CONTROLLER

© 2001 CURTIS INSTRUMENTS, INC.

DESIGN OF CURTIS PMC 1200 SERIES
CONTROLLERS PROTECTED BY U.S.
PATENT NO. 4626750.

CURTIS

CURTIS PMC

235 East Airway Boulevard
Livermore, California 94568 USA
Tel: 925-961-1088
Fax: 925-961-1099
www.curtisinst.com

1244 Manual, p/n 16958
Rev. B: January 2001

1244 Manual
p/n 16958, Rev. B: January 2001
© 2001 CURTIS INSTRUMENTS, INC.

CURTIS INSTRUMENTS, INC.
200 KISCO AVENUE
MOUNT KISCO, NEW YORK 10549 USA
☎ 914-666-2971 FAX 914-666-2188

CURTIS PMC
235 EAST AIRWAY BOULEVARD
LIVERMORE, CALIFORNIA 94550 USA
☎ 925-961-1088 FAX 925-961-1099

ADDITIONAL OFFICES located in
*Bulgaria, China, England, France, Germany,
India, Italy, Japan, Netherlands, Puerto
Rico, Russia, Sweden, and Switzerland*

www.curtisinst.com

WIRING : STANDARD CONFIGURATION

2 — INSTALLATION & WIRING: Controller

WIRING: Standard Configuration

Figure 3 shows the typical wiring configuration for most applications. The interlock switch is typically a seat switch, tiller switch, or foot switch.

Standard Power Wiring

Motor armature winding is straightforward, with the armature's A1 connection going to the controller's B+ bus bar and the armature's A2 connection going to the controller's M- bus bar.

The motor's field connections (**F1** and **F2**) to the controller are less obvious. The direction of vehicle travel with the forward direction selected will depend on




Fig. 3 Standard wiring configuration, Curtis PMC 1244 controller.

DIAGNOSTICS AND TROUBLESHOOTING

8 — DIAGNOSTICS & TROUBLESHOOTING

8

DIAGNOSTICS AND TROUBLESHOOTING

The 1244 controller provides diagnostics information to assist technicians in troubleshooting drive system problems. The diagnostics information can be obtained by observing the appropriate display on the handheld programmer, the fault codes issued by the Status LED, or the fault display driven by the controller's Fault 1 and Fault 2 outputs. Refer to the troubleshooting chart (Table 5) for suggestions covering a wide range of possible faults.

PROGRAMMER DIAGNOSTICS

The programmer presents complete diagnostic information in plain language. Faults are displayed in the Diagnostic Menu (see column 2 in the troubleshooting chart), and the status of the controller inputs/outputs is displayed in the Test Menu.

Accessing the Diagnostic History Menu provides a list of the faults that have occurred since the diagnostic history file was last cleared. Checking (and clearing) the diagnostic history file is recommended each time the vehicle is brought in for maintenance.

The following 4-step process is recommended for diagnosing and troubleshooting an inoperative vehicle: (1) visually inspect the vehicle for obvious problems; (2) diagnose the problem, using the programmer; (3) test the circuitry with the programmer; and (4) correct the problem. Repeat the last three steps as necessary until the vehicle is operational.

Example: A vehicle that does not operate in "forward" is brought in for repair.

STEP 1: Examine the vehicle and its wiring for any obvious problems, such as broken wires or loose connections.

STEP 2: Connect the programmer, select the Diagnostics Menu, and read the displayed fault information. In this example, the display shows "No Known Faults," indicating that the controller has not detected anything out of the norm.

STEP 3: Select the Test Menu, and observe the status of the inputs and outputs in the forward direction. In this example, the display shows that the forward switch did not close when "forward" was selected, which means the problem is either in the forward switch or the switch wiring.

STEP 4: Check or replace the forward switch and wiring and repeat the test. If the programmer shows the forward switch closing and the vehicle now drives normally, the problem has been corrected.

TROUBLESHOOTING CHART

8— DIAGNOSTICS & TROUBLESHOOTING

Table 5 TROUBLESHOOTING CHART

LED CODE	PROGRAMMER LCD DISPLAY	FAULT CATEGORY	EXPLANATION	POSSIBLE CAUSE
1,2	HW FAILSAFE1 - 2 - 3	1	self-test or watchdog fault	1. Controller defective.
1,3	M- SHORTED	1	internal M- short to B-	1. Controller defective.
	FIELD OPEN	1	field winding fault	1. Motor field wiring loose. 2. Motor field winding open.
	ARM SENSOR	1	armature current sensor fault	1. Controller defective.
	FLD SENSOR	1	field current sensor fault	1. Controller defective.
2,1	THROTTLE FAULT 1	1	wiper signal out of range	1. Throttle input wire open. 2. Throttle input wire shorted to B+ or B-.
	THROTTLE FAULT 2	1	pot low fault	1. Throttle pot defective. 2. Wrong throttle type selected.
2,2	SRO	3	SRO fault	1. Improper sequence of KSI, interlock, and direction inputs. 2. Wrong SRO type selected. 3. Interlock or direction switch circuit open. 4. Sequencing delay too short.
2,3	HPD	3	HPD fault	1. Improper seq. of direction and throttle inputs. 2. Wrong HPD type selected. 3. Misadjusted throttle pot. 4. Sequencing delay too short.
2,4	BB WIRING CHECK	1	emergency reverse wiring fault	1. Emergency reverse wire open. 2. Emergency reverse check wire open.
3,1	CONT DRVR OC	1	cont. driver output overcurrent	1. Contactor coil shorted.
3,2	MAIN CONT WELDED	1	welded main contactor	1. Main contactor stuck closed. 2. Main contactor driver shorted.
3,3	PRECHARGE FAULT	1	internal voltage too low at startup	1. Controller defective. 2. External short, or leakage path to B- on external B+ connection.
3,4	MISSING CONTACTOR	1	missing contactor	1. Any contactor coil open or not connected.
	MAIN CONT DNC	1	main contactor did not close	1. Main contactor missing or wire to coil open.
4,1	LOW BATTERY VOLTAGE	2	low battery voltage	1. Battery voltage < undervoltage cutback limit. 2. Corroded battery terminal. 3. Loose battery or controller terminal.
4,2	OVERVOLTAGE	2	overvoltage	1. Battery voltage > overvoltage shutdown limit. 2. Vehicle operating with charger attached. 3. Battery disconnected during regen braking.
4,3	THERMAL CUTBACK	2	over-/under-temp. cutback	1. Temperature >85°C or < -25°C. 2. Excessive load on vehicle. 3. Improper mounting of controller. 4. Operation in extreme environments.
4,4	ANTI - TIEDOWN	3	Mode 2 or Mode 4 selected at startup	1. Mode switches shorted to B+. 2. Mode switches "tied down" to select Mode 2 or Mode 4 permanently.

LED DIAGNOSTICS

8 — DIAGNOSTICS & TROUBLESHOOTING

LED DIAGNOSTICS

A Status LED is built into the 1244 controller. It is visible through a window in the label on top of the controller. This Status LED displays fault codes when there is a problem with the controller or with the inputs to the controller. During normal operation, with no faults present, the Status LED flashes steadily on and off. If the controller detects a fault, a 2-digit fault identification code is flashed continuously until the fault is corrected. For example, code “3,2”—welded main contactor—appears as:

□ □ □ □ □	□ □ □ □ □	□ □ □ □ □
(3 , 2)	(3 , 2)	(3 , 2)

The codes are listed in Table 6.

Table 6 STATUS LED FAULT CODES		
LED CODES		EXPLANATION
<i>LED off</i>	████████	no power or defective controller
<i>solid on</i>	□	controller or microprocessor fault
0,1	■ □	controller operational; no faults
1,1	□ □	[not used]
1,2	□ □□	hardware failsafe fault
1,3	□ □□□	M-, current sensor, or motor fault
1,4	□ □□□□	[not used]
2,1	□□ □	throttle fault
2,2	□□ □□	static return to off (SRO) fault
2,3	□□ □□□	high pedal disable (HPD) fault
2,4	□□ □□□□	emergency reverse circuit check fault
3,1	□□□ □	contactor driver overcurrent
3,2	□□□ □□	welded main contactor
3,3	□□□ □□□	precharge fault
3,4	□□□ □□□□	missing contactor, or main cont. did not close
4,1	□□□□ □	low battery voltage
4,2	□□□□ □□	overvoltage
4,3	□□□□ □□□	thermal cutback, due to over/under temp.
4,4	□□□□ □□□□	anti-tiedown fault

NOTE: Only one fault is indicated at a time, and faults are not queued up. Refer to the troubleshooting chart (Table 5) for suggestions about possible causes of the various faults.

PROGRAMMING PARAMETERS - E-500-80V & T-448HD**! WARNING !**

The owner of this vehicle shall ensure that the service technicians are qualified, properly trained and obey the safety rules and guidelines in OSHA and ANSI B56 regulations, and in this manual.

Before installing and/or programming the PMC, park the vehicle on a flat level surface, lift the wheels off the ground and secure with jack stands of adequate capacity. Don't connect charger.

Programmable controllers must be programmed using the parameter settings in this service manual, before connecting the motor, to avoid sudden vehicle movement and accident.

Do not try to increase motor speed by changing parameter settings in the speed controller; it can cause accident and severe damage to the motor.



VOLTAGE	NOMINAL BATTERY VOLTAGE, IN VOLTS	7	THRO. DEADBAND	Thr. Neutral deadband % of 5kohms pot	6
M1 DRIVE C/L	MODE 1 DRIVE CURRENT LIMIT, IN AMPS	350	THROTTLE MAX	Thr. Input req'd for 100%PWM %5kohm pot	90
M2 DRIVE C/L	MODE 2 DRIVE CURRENT LIMIT, IN AMPS	350	M1 THRTL MAP	MODE 1 THROTTLE MAP, AS %	30
M3 DRIVE C/L	MODE 3 DRIVE CURRENT LIMIT, IN AMPS	350	M2 THRTL MAP	MODE 2 THROTTLE MAP, AS %	30
M4 DRIVE C/L	MODE 4 DRIVE CURRENT LIMIT, IN AMPS	350	M3 THRTL MAP	MODE 3 THROTTLE MAP, AS %	30
M1 BRAKE C/L	MODE 1 BRAKING CURRENT LIMIT, IN AMPS	150	M4 THRTL MAP	MODE 4 THROTTLE MAP, AS %	30
M2 BRAKE C/L	MODE 2 BRAKING CURRENT LIMIT, IN AMPS	150	FIELD MIN	MIN. FIELD CURRENT, IN AMPS	10
M3 BRAKE C/L	MODE 3 BRAKING CURRENT LIMIT, IN AMPS	150	FIELD MAX	MAX. FIELD CURRENT, IN AMPS	50
M4 BRAKE C/L	MODE 4 BRAKING CURRENT LIMIT, IN AMPS	150	FIELD MAP START	Armature current at wch FIELD MAP takes effect, amps	100
M1 THRT BRK %	MODE 1 THROT. BRAKING, AS % OF BRAKE C/L	50	FIELD MAP	Field Winding Current, as % of Armature Current	50
M2 THRT BRK %	MODE 2 THROT. BRAKING, AS % OF BRAKE C/L	50	CURRENT RATIO	CURRENT RATIO:FACTOR OF 1, 2, 4 OR 8	1
M3 THRT BRK %	MODE 3 THROT. BRAKING, AS % OF BRAKE C/L	50	RESTRAINT	RAMP RESTRAINT: 1 TO 10	3
M4 THRT BRK %	MODE 4 THROT. BRAKING, AS % OF BRAKE C/L	50	LOAD COMP	LOAD COMPENSATION: 0 TO 25	0
M1 ACCEL RATE	MODE 1 ACCELERATION RATE, IN SEC.	4	HPD	HIGH PEDAL DISABLE (HPD) TYPE	1
M2 ACCEL RATE	MODE 2 ACCELERATION RATE, IN SEC.	4	SRO	STATIC RETURN TO OFF (SRO) TYPE	1
M3 ACCEL RATE	MODE 3 ACCELERATION RATE, IN SEC.	4	SEQUENCING DLY	SEQUENCING DELAY, IN SEC.	1
M4 ACCEL RATE	MODE 4 ACCELERATION RATE, IN SEC.	4	MAIN CONT INTR	MAIN CONTACTOR INTERLOCK: ON OR OFF	ON
DECEL RATE	DECELERATION RATE, IN SEC.	2.5	MAIN OPEN DELAY	MAIN CONTACTOR DROPOUT DELAY, IN SEC.	1
M1 BRAKE RATE	MODE 1 BRAKING RATE, IN SEC.	3	WELD CHECK	MAIN CONTACTOR WELD CHECK: ON OR OFF	ON
M2 BRAKE RATE	MODE 2 BRAKING RATE, IN SEC.	3	MAIN CHECK	MAIN COIL OPEN CHECK: ON OR OFF	ON
M3 BRAKE RATE	MODE 3 BRAKING RATE, IN SEC.	3	AUX ENABLE	AUXILIARY ENABLE: ON OR OFF	ON
M4 BRAKE RATE	MODE 4 BRAKING RATE, IN SEC.	3	EM BRAKE	ELECTROMAGNETIC BRAKE ON OR OFF	OFF
QUICK START	QUICK START THROTTLE FACTOR	1	AUX DELAY	AUXILIARY DRIVER DROPOUT DELAY, IN SEC.	4
TAPER RATE	Regen brak. Decrease rate when apporch. 0spd, 1/32s	32	AUX CHECK	AUXILIARY COIL OPEN CHECK: ON OR OFF	ON
M1 MAX SPEED	MODE 1 MAX. SPEED, AS % PWM OUTPUT	40	EM BRAKE DELAY	ELECTROMAGNETIC BRAKE DELAY, IN SEC.	0
M2 MAX SPEED	MODE 2 MAX. SPEED, AS % PWM OUTPUT	100	EM BRAKE CHECK	ELECTROMAG. BRAKE OPEN CHECK: ON OR OFF	OFF
M3 MAX SPEED	MODE 3 MAX. SPEED, AS % PWM OUTPUT	40	REV DRVR CHECK	REVERSE SIGNAL OPEN CHECK: ON OR OFF	OFF
M4 MAX SPEED	MODE 4 MAX. SPEED, AS % PWM OUTPUT	40	CONT PULL IN	CONTACTOR COIL PULL-IN VOLTAGE, AS %	50
M1 CREEP SPEED	MODE 1 CREEP SPEED, AS % PWM OUTPUT	0	CONT HOLDING	CONTACTOR HOLDING VOLTAGE, AS %	48
M2 CREEP SPEED	MODE 2 CREEP SPEED, AS % PWM OUTPUT	0	EMR REV ENABLE	EMERGENCY REVERSE FUNCTION : ON OR OFF	OFF
M3 CREEP SPEED	MODE 3 CREEP SPEED, AS % PWM OUTPUT	0	EMR REV C/L	EMERGENCY REVERSE CURRENT LIMIT, IN AMPS	50
M4 CREEP SPEED	MODE 4 CREEP SPEED, AS % PWM OUTPUT	0	EMR REC CHECK	EMERGENCY REV. WIRING CHECK : ON OR OFF	OFF
REGEN SPEED	Min. speed for regen braking, as % of vehicle speed	25	ANTI-TIEDOWN	ANTI-TIEDOWN: ON OR OFF	OFF
CTRL MODE	CONTROL MODE	1	FAULT CODE	ON OR OFF	ON
THROTTLE TYPE	THROTTLE TYPE	3	PEDAL INTERLOCK	THREADLE, PB-6, CHECK WIRING	OFF
			PRECHARGE	ON OR OFF	ON

SPARE PARTS

BODY





REF.	PART NO	DESCRIPTION
1	2382320009	SEAT BACK CUSHION
	2383320004	SEAT CUSHION
	2385320003	BUCKET SEAT ON SLIDE ADJUSTER <i>(Not illustrated)</i>
2	2384300009	BACKREST FRAME WITHOUT REAR LIGHT
	2384448010	LIGHT HOLDER FOR 2384448014 <i>(Not illustrated)</i>
	2384448014	BACKREST FRAME FOR REAR LIGHTS <i>(Not illustrated)</i>
3	2331448012	BATTERY COVER
4	2330448004	MOTOR COVER – HORIZONTAL
	2330448006	MOTOR COVER – INCLINED
5	2339448004	CONTROLS COVER
6	2223360004	5.00 X 8 SOLID SOFT RUBBER WHEEL, RIB TREAD
	2223360003	5.00 X 8 SOLID SOFT RUBBER WHEEL, LUG TREAD
7	2314320001	FRONT BUMPER
8	120003	TRIMMING
9	2803300008	RIGHT HANDLE
	2803300009	LEFT HANDLE

CAB


REF	PART NO	DESCRIPTION
1	2360448009	STEEL CAB
	2382320009	SEATBACK CAB
2	2360320014	RIGHT DOOR
	2360320015	LEFT DOOR
3	2803000003	PADDLE LATCH
	2366320015	DOOR LATCH
4	2365000001	RIGHT HINGES KIT
	2365000002	LEFT HINGES KIT
5	2367320002	RIGHT DOOR GLASS
	2367320001	LEFT DOOR GLASS
6	2801000002	REAR VIEW MIRROR

REF	PART NO	DESCRIPTION
7	2802000001	TRIM DOOR
8	2801000001	SIDE MIRROR
9	2399000014	SIDE MIRROR BRACKET
10	3113000001	WIPER MOTOR
	2800000002	WIPER
	2800000001	ARM
11	2366320001	DOOR HANDLE
12	2366320002	DOOR HANDLE BAR
13	2366320003	DOOR LEVER
14	2367300001	REAR GLASS
15	2367300002	WINDSHIELD

FORD F-150 DIFFERENTIAL




REF	DESCRIPTION	QTY.	PART NO.
1	Shaft, Axle	2	Contact manufat.
2	Wheel stud	10	2910000001
	Wheel nut	10	2910000019
3	Retainer plate	2	2179000011
4	Oil seal	2	2104448001
5	Spherical bearing	2	2103448001
6	Retaining ring	2	2179000012
7	Housing	1	Contact manufat.
8	Spacer, calliper support	4	2122236003
9	Mounting plate, caliper	2	2122236001
10	Bolt 1/2-nf x 5", grade 5		
	Bolt 1/2-nf x 2 1/2", grade 5		
	Lock washer 1/2"	10	
11	Breather	1	2179000033
12	Housing stud	10	2179000016
13	Bearing Cone & cup – 2.89" O.D.	2	2103000021
	Bearing Cone & cup – 3.06" O.D.	2	2103000001
14	Ring & pinion gear kit	1	Contact manufat.
15	Shaft	1	2179000001
16	Spring pin	1	2179000061
17	Open carrier case, kit (included item 15 to 21)	1	2179000020
18	Washer for small spider gear	2	2179000062
19	Small spider gear	2	2116000011
20	Big spider gear	2	2116000002
21	Washer for big spider gear	2	2179000014
22	Bolt 7/16-NF x 1", grade 8	10	
	Flat washer 7/16"	10	
23	Button socket cap screw 5/16-NC x 3/8"	2	2179000057
24	Lock	2	2179000058
25	Shim (differential bearing adjustment), 80mm O.D.	2	2179000059
	Shim (differential bearing adjustment), 2.97" O.D.	2	2179000060
26	Bolt 1/2-NC x 2", grade 8	4	
27	Nylon-Insert Hex Locknut 3/8-NF	10	
28	Gear case	1	2179000018
29	Plug, 1/2" NPT	1	
30	Pinion depth shim, 0.005"		2179000023
	Pinion depth shim, 0.010"		2179000024
	Pinion depth shim, 0.013"		2179000025
31	O-ring, pinion support	1	2179000055
32	Pocket bearing	1	2103448008
33	Retainer, pocket bearing	1	2179000056
34	Bearing Cone & cup – 2.39" O.D.	1	2103000004
	Bearing Cone & cup – 3.00" O.D.	1	2103000019
35	Pinion support	1	2179000019
36	Bolt 3/8-NC x 1 1/2"		
	Bolt 3/8-NC x 2"		
	Lock washer 3/8"		
37	Solid spacer, pinion	1	2179000022
38	Pinion pre-load shim, 0.002"		2179000026
	Pinion pre-load shim, 0.005"		2179000027
	Pinion pre-load shim, 0.010"		2179000028
39	Bearing Cone & cup	1	2103000004
40	Shielding disc for seal	1	2179000063
41	Oil seal, pinion – 2.75" O.D.	1	2104448003
	Oil seal, pinion – 3.00" O.D.	1	2104448002
42	Pulley W80, 8.00" O.D.	1	2113000003
	Pulley W90, 9.00" O.D.	1	2113000004
43	Machined nut, pinion	1	2179000013
44	Wheel nut	10	2910000019
45	Drum	2	2123480003
46	Brake assembly, left hand	1	2124480003
	Brake assembly, right hand	1	2124480004
47	Retainer plate	2	2179489001
48	Retainer ring	2	2179489002
n/a	Drain Plug, magntic	1	2179000015

BRAKE CONTROLS

REF	PART NO	DESCRIPTION	QTY	REF	PART NO	DESCRIPTION	QTY
1		Nut 1/4-20UNC	1	14	2190000003	Spring (Extention)	1
2	2910000015	Yoke	1	15	2910000013	Yoke	1
3		Lock washer ¼	1	16		Cotter pin 3/32 x 1	1
4	2930000012	Lubrication fitting	1	17		Flat washer 5/16	2
5	2131100002	Rubber pad	1	18		Clevis pin 5/16 x 1-1/2	1
6	2131448001	Lever	1	19	2139240002	Handbrake lever	1
7	2133280001	Push rod-Master cylinder	1	20	2129000003	Handbrake cable	1
8		Nut 3/8-16UNF	1	21	2129000001	Clip	1
9	2132448001	Pivot	2	22	2921000001	Cable stop	1
10		Boot, included with #2125000001	1	23	2127000006	Handbrake band (side cable)	1
11	2125000001	Master cylinder	1	24	2127000001	Handbrake band	1
12	2910000028	Clevis pin 3/8 x 1-3/32	1	25	2191240002	Spring (compression)	1
13		Cotter pin 3/32 x 1	1				


FRONT AXLE, SUSPENSION, STEERING, DISC BRAKES



REF	PART NO	DESCRIPTION	REF	PART NO	DESCRIPTION
1	2100300002*	BUSHING	41	2224300002	HUB
	2100300001*	BUSHING WITH OIL SEAL		2910300003	WHEEL BOLT
2	2100300003*	BUSHING	42	2229300001	DUST CAP
3	2103250001	THRUST BEARING	43	2229300002	OIL SEAL
4	2103300001	TAPER BEARING	44	2229300003	SPINDLE WASHER
5	2103300002	TAPER BEARING	45	2910000005	NUT, LEFT HAND
6	2104300004*	OIL SEAL	46	2910000006	NUT, RIGHT HAND
7	2117250001*	GEAR	47	2910000017	BOLT, LONG
8	2120236001	DISC	48	2910000018	BOLT, SHORT
9	481431K	RIGHT CALIPER	49	2910000019	WHEEL NUT
10	481430K	LEFT CALIPER	50	2910000020*	LOCK WASHER 7/8
11	2121000005	BUSHING, LONG	51	2910000021*	JAM NUT 7/8-NF
12	2121000006	BUSHING, SHORT	52	2910000022*	JAM NUT 3/4-NF
13	2122300001	LEFT CALIPER SUPPORT	53	2910000023*	SPRING PIN 1/4 X 1 3/4
14	2122300002	RIGHT CALIPER SUPPORT	54	2910000024*	SET SCREW 5/16-NC
15	2128280001	PADS	55	2910300001	CASTELLATED NUT 3/4-NF
16	2128280001	PADS	56	2910300002	CASTELLATED NUT 1-UNEF
17	2129000001	CLIP	57	2914364001	BUSHING
18	2134000001	FLEXIBLE HOSE	58	2916000001	U-BOLT
19	2139000001	CALIPER PROTECTOR	59	2930000012	GREASE FITTING
20	2139000002	WASHER	60		BOLT 3/8-NC X 1 1/2
21	2139000003	BOLT	61		BOLT 5/16-NC X 1 1/4
22	2180240001	SHOCK ABSORBER	62		BOLT 5/16-NC X 1
23	2182320001	SHACKLE LINK	63		BOLT 5/8-NC X 4
24	2184448001	PLATE	64		BOLT 7/16-NC X 2
25	2192280001	LEAF SPRINGS	65		CARRIAGE BOLT 1/4-NC X 3/4
26	2200300002*	TUBE	66	2910000041	HEAVY NUT 1/2-NF
27	2200300003*	SHAFT	67		NUT 1/4-NC
28	2201320001	AXLE BEAM	68		NUT 3/8-NC
	2201448009	AXLE BEAM, PWR STEERING	69		NUT 5/16-NC
29	2201360001	LEFT SPINDLE, BRAKES	70		FLAT WASHER 1/4
	2201662003	LEFT SPINDLE, PWR STEERING	71	2910000042	FLAT WASHER 12mm
30	2201360002	RIGHT SPINDLE, BRAKES	72		FLAT WASHER 7/16
	2201662002	RIGHT SPINDLE, PWR STEERING	73		COTTER PIN 3/16 X 2
31	2205250001	KING PIN	74		COTTER PIN 7/64 X 2
32	2206300003	STEERING SUPPORT,	75		MACHINE SCREW 1/4-NC X 3/8
33	2207000001	ROD END, LEFT HAND	76		NYLON NUT 5/8-NC
34	2207000002	ROD END, RIGHT HAND	77		LOCK WASHER 1/4
35	2207320001*	FRONT TIE ROD	78		LOCK WASHER 5/16
36	2207300006	REAR TIE ROD	79		LOCK WASHER 3/8
37	2207320009*	ARM	80		LOCK WASHER 7/16
38	2208240001*	STEERING WHEEL			
39	2208240002*	COVER			
40	2219250001*	SPACER			

* APPLICABLE ON VEHICLE WITHOUT POWER STEERING.

TILT STEERING WHEEL




REF	PART NO	DESCRIPTION	REF	PART NO	DESCRIPTION
1	2208224002	HORN BUTTON	12	3109210001	GREY HANDLE
2	2208224001	STEERING WHEEL	13	3109210004	NAMEPLATE F/R
3	2219224002	HORN BRUSH KIT	14	2392224001	CASE F/R
4	2200224004	TILT / TEL COLOMN	15	3109210002	SWITCH
5	2330015	UNIVERSAL JOINT	16	3109210003	CONTACT BLOCK
6	2200224003	SHAFT	17	2206448001	COLOMN SUPPORT – before serial #1117032
7	2809000001	RUBBER BOOTS		2206320003	COLOMN SUPPORT – serial #1117032 & after
8	2200224001*	NYLON COUPLER – 2 1/2"	18	2200224007	BUSHING
	2200248002*	NYLON COUPLER – 3 1/4"	19	2200224006	WASHER
9	2200224002	SHAFT	20		FLAT WASHER 5/16
10	2104000001	UNIVERSAL JOINT	21		LOCK WASHER 3/8
11	2117448001	GEAR	22		HEAVY BOLT 3/8-NC X 1 1/2

* SELECT APPROPRIATE LENGTH OR CONTACT MANUFACTURER.

MOTOR AND DRIVE

<i>REF.</i>	<i>PART NO</i>	<i>DESCRIPTION</i>
1	3112720001	MOTOR ASSEMBLY
2	3112720002	FRAME AND FIELD COIL
3	3112720003	ARMATURE ASSEMBLY
4	3112720004	BRUSH
5	2154448001	FRONT MOUNT, MOTOR
6	2160448001	REAR MOUNT, MOTOR
7	2113000018	PINION PULLEY
8	2113000004	MOTOR PULLEY
9	4851001	BELT


REAR SUSPENSION AND BRAKE

REF	PART NO	DESCRIPTION	REF	PART NO	DESCRIPTION
1	2120236001	DISC	15	2185280001 2185280002*	FORD PLATE or GM PLATE
2	481431K 481430K	RIGHT CALIPER LEFT CALIPER	16	2192320001	5 - LEAF SPRINGS
3	2121000005	BUSHING, LONG	17	2910000017	BOLT, LONG
4	2121000006	BUSHING, SHORT	18	2910000018	BOLT, SHORT
5	2122236001	MOUNTING PLATE, CALIPER	19	2916280002 2916280002*	U-BOLT 1/2-NF X 3 1/4" I.D. or U-BOLT 1/2-NF X 3 1/4" I.D. (short)
6	2122300001 2122300002	LEFT CALIPER SUPPORT RIGHT CALIPER SUPPORT	20	2916480002 2916280002*	U-BOLT 1/2-NF X 4" I.D. or U-BOLT 1/2-NF X 3 1/4" I.D. (long)
7	2128280001	PADS	21		BOLT 5/8-NC X 4
8	2128280001	PADS	22	2910000041	HEAVY NUT 1/2-NF
9	2129000001	CLIPS	23	2910000042	FLAT WASHER 12mm
10	2134000001	FLEX. HOSE	24		MACHINE SCREW 1/4-NC X 3/8
11	2139000002	WASHER	25		NYLON NUT 5/8-NC
12	2139000003	BOLT	26	2183240002	BUSHING
13	2182320002	SHACKLE LINK			
14	2182448004	REAR SUSPENSION PLATE - BEFORE SERIAL #1081327			

* NEW FORD HOUSING (SERIAL #1071613 AND UP):


NEED THE LEAF SPRING PLATE 2185320002 AND U-BOLT 1/2-NF x 3 1/4" I.D. 2916280003.

ELECTRICAL DIAGRAM – SEPEX MAIN CIRCUIT **DIAGRAMME ÉLECTRIQUE – CIRCUIT PRINCIPAL SEPEX**




MOTREC INC.			
SUBJECT:	SEPEX 1244 - POWER STEERING		
TITLE:	MAIN CIRCUIT-SEPEX		
VERSION:	01	DATE:	2005-10-26
AUTHOR:	J. GAGNON	APPROVED:	
DRAWING #:	SEPEX 1244-POWER STEERING.VSD		

ACCESSORIES – DC-DC CONVERTER ACCESSOIRES – CONVERTISSEUR DC-DC



MOTREC INC.	
SUBJECT:	ACC - 2HL2TL2BL1SL1WM
TITLE:	ACCESSOIRES - DC/DC CONVERTER
VERSION:	01
AUTHOR:	J. GAGNON
DATE:	2006-04-06
APPROVED:	
DRAWING #	ACC - DC-DC - 2HL2TL2BL1SL1WM.VSD

OPTIONS




MOTREC inc.			
SUBJECT: OPTIONS - FLASHERS			
TITLE: OPTIONS			
VERSION :	01	DATE:	2006-04-07
AUTHOR :	J. GAGNON	APPROVED:	
DRAWING #:	OPTIONS - FLASHERS.VSD		

PARTS LIST

NO	DESIGNATION	REF	QTY
A2	SEPEX SPEED CONTROL	1244-6661	1
A3	I.D. PMC		
B1	STROBELIGHT	*	1
B2	HORN	*	1
B3	REVERSE ALARM	*	1
B4	HANDBRAKE ALARM	3100000005	
E1.A,B	HEADLIGHT	*	2
E2.A,B	TAIL/BRAKE LIGHT	*	2
E3.A,B	AMBER FRONT LIGHT	*	2
E4.A,B	BACKUP LIGHT	*	2
F1.A,B	FUSE, 15A	246108K	2
F3	CIRCUIT BREAKER, 150A	3107000002	1
F4	DIODE	367012	
F5	DIODE BRIDGE	3669027	1
F7	MAXI BLADE FUSE, 30A	3118501005	1
	MAXI FUSE HOLDER	3118501006	1
	DUST CAP	3118501007	1
F8.A,B	FUSE, 5A		
G1	BATTERY		
G3	BATTERY – AA TYPE	14602	
	BATTERY HOLDER	3101000008	
K1	FLASHER RELAY	3069004	1
K2	RELAY	3127248002	
M2	SEPEX MOTOR		1
M3	POWER STEERING MOTOR	3112800002	1
M4	WIPER MOTOR	*	1
P1	INDICATOR (BDI), HOUR METER	3108448001	1
R1	ACCELERATOR	2142100001	1
	MICROSWITCH	3109100001	1
	POTENTIOMETER	367003	1
	PLASTIC GEAR	367015	1
	SPRING	2462008	1
S1	KEY SWITCH	246205	1
S3	SEAT SWITCH, MICRO-SWITCH	3109100002	1
S7	FORWARD/REVERSE SELECTOR	266211	1
S8	LIGHT SWITCH, ROCKER TYPE	1269004	1
	LIGHT SWITCH, PUSH/PULL	486002	1
S10	HORN BUTTON	*	1
S12	BRAKE LIGHT SWITCH	246207	1
	HYDRAULIC BRAKE LIGHT SWITCH	3669004	1
S13	FLASHER SWITCH	*	1
S15	EMERGENCY PUSH BUTTON	3109800001	
	EMERGENCY PUSH BUTTON, LABEL	3109800006	
S19	EMERGENCY PUSH BUTTON	3109000005	1
	EMERGENCY STOP LABEL	3109800006	1
S20	HANDBRAKE SWITCH	3109100002	1
U1	DC-DC CONVERTER	3124880001	1
X1	HOUR METER CONNECTOR		1
X2	SPEED CONTROL CONNECTOR		1
X3	I.D. PMC CONNECTOR		
Y1	MAIN CONTACTOR	486222	1
Y2	AUX CONTACTOR	486222	1
Y10	HEATER SOLENOID	246101	1
	STATIC STRAP	2450001	1

* Consult Motrec Illustrated parts

HYDRAULIC DIAGRAM



PARTS LIST

NO	DESCRIPTION	REF	QTÉ
A	HYDRAULIC UNIT – STEERING	4190448001	1
B	POWER STEERING PUMP	*	1
C	RELIEF VALVE	*	1
D	FILTER	*	1
E	STEERING CYLINDER	4130448001	1

* Contact manufacturer

MOTREC ILLUSTRATED ACCESSORIES

 <p>Strobe light, pole mount Amber 12-80V: 3116000002 Red 12-80V: 2469001 Blue 12-80V: 3690008</p>	 <p>Red Tail/Brake light Grommet: 3269001 Plug: 246012A 12V : 2469021 24V : 2469022</p>	 <p>Red Tail/Turn LED light 12-24V: 3111000037</p>	 <p>Multi-LED Back-up Light: 3111000007 Strobe light: 3111000013 Grommet: 3111000008 Plug: 3119000009</p>
 <p>Strobe light, cab mount Amber 12-48V: 3116250001 Red 12-48V: 3069026 Blue 12-48V: 3069014 Amber 72-80V: 3116720001 Red 72-80V: 3116720002 Blue 72-80V: 3116720003</p>	 <p>Red Tail/Brake light ** Model EE ** Assembly: 3111000030 Housing: 3111000027 Plug: 3111000029 12V : 3111000028</p>	 <p>Clear lamp Incandescent 12V: 3111000039 Clear lamp LED 12V: 3111000042 Bulb incandescent 12V : 1269008 Bulb 12V LED: 3117000001</p>	 <p>Back-up lamp Grommet: 3269001 12V: 3669012 24V: 3669012A</p>
 <p>Amber turn lamp 12V: 3111000022 Bulb 12V: 3069021 Multi-LED amber turn lamp Round Light: 3111000010 Grommet: 3111000008 Plug: 3111000009</p>	 <p>Red Tail/Brake light Housing: 3111000041 Red Tail/Brake light Housing LED: 3111000044 Bulb 12V: 3117240001 Bulb 12V LED: 3117000010</p>	 <p>Oval lamp 12V: 3111330001</p>  <p>LED Headlight 12V: 3111000036</p>	 <p>Pedestal head lamp 12V: 3111240001 Bulb 12V: 2569001B Bulb 24V: 2169001B</p>
 <p>Amber turn lamp 2" 12V : 3111330002</p>	 <p>Multi-LED Red Tail/Brake Light: 3111000006 Grommet: 3111000008 Plug: 3119000009</p>	 <p>Headlight Left: 3111480003 Right: 3111480004 Bulb H/L: 3111480006 Bulb Turn: 3111480008 Bulb Mark: 3111480007</p>	 <p>Pedestal head lamp - LED 12-48V: 3111000034</p>
 <p>Amber turn lamp 2" LED white background 12V : 3111330003</p>	 <p>Red Tail/Brake light 12V: 386002</p>	 <p>Headlight Left: 3111480003 Right: 3111480004 Bulb H/L: 3117480001 Bulb Turn: 3117480003 Bulb Mark: 3117480002</p>	 <p>Headlamp 12V: 3111250007</p>
 <p>Red Tail/Turn/Rev light 12V: 3111000002</p>	 <p>Red Tail/Turn LED light 12-24V: 3111000037</p>		 <p>Headlamp 12V: 3111300001 Bulb 12V: 3111300002</p>

 <p>Analog Voltmeter 12V : 3069007 24V : 3069002 36-48V : 3669002</p>	 <p>Wiper motor 12V: 3113000001 24V: 486211</p>	 <p>Cab heater 12V: 3103300001 36V: 3669008 48V: 4869020</p>	 <p>Horn 12V: 246003 24V: 246013</p>
 <p>HOBBS Gauge 24V: 2469026 36V: 3069038 48V: 4869037</p>	 <p>Wiper arm 2800000001</p>	 <p>12V Dome light 3669006</p>	 <p>Horn button VIP 2208224002</p>
 <p>DC-DC converter, 10A 12-48V: 3069019</p>	 <p>Wiper blade 14" Blade: 2800000002 18" Blade: 2800000003</p>	 <p>12V Fan 3669013</p>	 <p>Horn button, column mount 3109000011</p>
 <p>DC-DC Converter, 25A 12-48V: 3124000002 72-80V: 3124880001</p>	 <p>Pantograph wiper arm 246233A</p>	 <p>Back-up alarm or Motion beeper 12-48V : 3100000001 72-80V : 3105720001</p>	 <p>Horn button, dash mount 266210</p>
 <p>DC-DC Converter, 300W 24V: 3124224001 36-48V: 3124280001 72-80V: 3124880001</p>	 <p>Pantograph wiper blade 246233</p>	 <p>12-24V Adjustable ECCO: 3100000002</p>	 <p>Horn button 3109250001</p>
 <p>CONNECTOR:3124280002</p>	 <p>Limit switch 3109000029</p>	 <p>12-48V Adjustable PRECO: 3100000004</p>	 <p>Turn signal switch 246050</p>
		 <p>Red Pilot light 12V: 246212 Bulb 12V: 246212B</p>	

ADDENDUM

CURTIS FOOT PEDAL

